





LOCATION

REP	EPLACEMENT PARTS LIST - SPECIFY FIGURE NO. WHEN ORDERING									
No.	DESCRIPTION	No.	DESCRIPTION							
1 1a 1b 1c 2 3 4 5 6 7	Head/Casing Assembly Head Casing Valve Housing Locking Device Key Cover Hydrant Cover Hinge Pins (2) Box Face Nut	8 9 10 10a 10b 10c 13 17 18	Operating Screw Operating Screw "O" Ring Operating Rod Assembly Coupling Rod Plunger Removable Seat Plunger "O" Ring Plunger "O" Ring							

▲THESE REPLACEMENT PARTS AVAILABLE IN HPRK-41

MAINTENANCE INSTRUCTIONS

- 1. Shut off water supply.
- Remove face nut.
 Pull stem out for complete access to all working parts.
 Check all working parts for replacement.
 Replace complete stem assembly and face nut.

ļ	ũ						WEIGHT POUNDS	VOLUME CUBIC FEET	FIGURE NUMBER
FIGURE NUMBER	Α	6-28-93	Submittal Update	EMB	CL			5810. 5811-CAN	
	REV.	DATE	DESCRIPTION	BY	CKD. BY				

PARTS LIST WITH MAINTENANCE INSTRUCTIONS

CO.