S2000 Field Service Solutions, LLC

PM Work Order

P O Box 277 Allen Park, MI 48076		(800) 643-1339 x 10 (505) 894-3336 (fax)			Number: 14	02
Customer:	Academy Of Merit	Мар:	5-A18		Entered: 11/13/20	06
	30548 Southfield Rd	Fax:				
# 9	Southfield, MI 48076	Cell:	(913) 890-8707			
Bill To: # 2	Superior Property Mgmt. 12 Island Way, Suite 200 Long Island, NY 11722		PO Num	t by: Bill Out ber: ble?: YES	Tax at: Cust	
Special:	Must read atttached not		Call Type:	PM Contract		
Comments:	Air Compressor		Priority:	Low		
			Agreement:	95		
WO Contact: Customer Note	Jim Merit es:	(913) 555-1709 x101	Sched:	12/11/06		

Probable CauseBlah blah blah

Action Taken: Gave them all software editions for free. 11-1 Dean Demo for 35 minutes he like iga;d

Work Order Notes:

Equipment & Tasks							
Eqp: Miscellaneous, , Ser #	Location: System No.:	187	Alt. System No.:				
<< Task: Air Compressor	Skill: Estimated Hours:	0.75	Tech:				
Part Number Descri	otion		Required	Used			

Examine area for safety hazards

Before beginning, inspect unit & surrounding area for any safety hazards. Document any problem areas.

Examine exterior surface of unit

Inspect exterior surface for leaks, hot spots, and surface corrosion.

Examine motor

When unit is not operating, inspect shaft of motor for excessive play. Lubricate & inspect bearings if necessary. With unit operating, listen to motor for any excessive vibration or uncommon noises.

Check controls & starter panel

Inspect the incoming wiring & starter coils. Check for burnt or pitted contacts.

Check belts

Check belts for proper tension and wear. Adjust belts or replace as needed.

Examine compressor oil & oil reservoir

Inspect compressor oil to ensure unit has no serious problems. Inspect oil reservoir for any cracks or leakage.

Examine oil cooler & fan

Inspect oil cooler for any foreign material & clean cooler. Inspect oil cooler fan. Lubricate & inspect bearings. Test for proper operation.

Examine oil separator

Inspect pressure drop across oil separator. Replace if necessary.

Examine air filters

Inspect filter section & filters. Clean or replace filters as necessary.

Examine air tank

Inspect air tank for any signs of leakage. Drain tank until only air is coming out.

Examine water separators

Inspect water separators & drain. Test for proper operation.

Examine safety relief valve

Inspect safety relief valve. Test for proper operation by lifting release for a moment. After letting go, be sure that valve resets.

Examine water traps

Inspect all water traps for any signs of leakage or failure. Check float operation.

Check List:

Special Actions:

Equipment Notes: