

CONNECTIVITY QUICK START GUIDE



MZD-CONNECT

MZD-CONNECT INFOTAINMENT SYSTEM

The MZD-Connect system is divided into five sections as displayed on the Home screen. The Home screen can be accessed at any time by pressing the **Home** button.



APPLICATIONS

- Fuel Economy Monitor including i-stop status and i-ELOOP status (where fitted)
- View service and maintenance information
- View vehicle warnings.



ENTERTAINMENT

- AM/FM/DAB (where fitted) radio, CD/MP3, USB, AUX and Bluetooth® audio
- Aha™ and Stitcher™ apps for internet radio, Facebook and Twitter*
- Listen to a connected device such as an iPod® or USB storage device.

*With compatible mobile device. Data usage and costs will vary. Please visit the **Find a Phone, Pair a Phone** section of mazda.co.uk/mzd-connect for more information regarding device compatibility.

CONTROLLING THE SYSTEM

There are three ways to control the system:

1. Using the 7" colour touch-screen
2. Using the Multimedia Commander
3. Using the steering wheel-mounted controls or voice control system.

Please note:

The touch-screen is disabled above 5mph for safety reasons.



USING THE COLOUR TOUCH-SCREEN

The touch-screen can be used when the vehicle is stationary or travelling below 5mph. The screen accepts touch, tap, slide and swipe motions and can control the entire infotainment and connectivity system. For example you can swipe the screen to scroll through a long list of contacts or slide the screen to tune in a radio station.

Please note:

Please do not use any sharp objects such as a pen or key to interact with the touch-screen. These could damage or pierce the screen and may cause a malfunction of the system.

For more information on any of the topics covered in this guide as well as detailed how-to guides for most functions please visit mazda.co.uk/mzd-connect



COMMUNICATION

- Easily make and receive phone calls*
- Receive texts and reply with programmable pre-defined responses*
- Access previous call history or contact information*.



NAVIGATION (WHERE FITTED)

- Choice of routes - fastest, shortest, most economical, and easiest
- 3 years free map updates
- Point of interest search.



SETTINGS

- Easily adjust audio, vehicle and other settings
- Adjust the Active Driving Display (where fitted).

VOICE CONTROL

To use voice control, press the **TALK** button located on the steering wheel and say a command after the beep. The system can be interrupted by pressing the **TALK** button again and speaking after the beep.

At any time, simply say "**Tutorial**" or "**Help**" for more information.



TALK BUTTON

The system responds to a large number of commands that perform simple operations, such as calling a contact in your phone book. For example "Call Matt at home" would dial the contact Matt on their home telephone number.

COMMON COMMANDS

Go to (and one of the following)

- Main Menu
- Entertainment
- Communication
- Navigation
- Settings
- Texts
- Contacts
- Call History.


Other common commands:

- Help
- Cancel
- Go Back or Previous
- Next or Skip
- Select (and line number);
e.g. Select Four or Select Line Four
- Turn Display Off
- Go to CD.

For more information regarding voice control and to view or download a list of voice commands please visit mazda.co.uk/mzd-connect

MULTIMEDIA COMMANDER

Your vehicle will be fitted with one of two Multimedia Commander types. Both share identical buttons and functions but have a slightly different layout in certain vehicles.



The Multimedia Commander is used to control all of the functions of the infotainment and connectivity system and can be moved left/right/up/down as well as turning to navigate through the menus.

Press the commander button to select a feature or enter a command.

- 1 **Entertainment** - access the audio menu.
- 2 **Home** - return to the main menu screen.
- 3 **Navigation** - access the navigation menu.
(where navigation is not fitted a GPS location screen will be displayed)
- 4 **Volume** - turn to adjust volume. Push down to mute audio.
- 5 **Favourites** - access your stored favourites:
50 radio stations across AM/FM/DAB (where fitted)
50 contacts
50 navigation points (where navigation is fitted).
- 6 **Back** - returns to previous screen.

BLUETOOTH®

For more information regarding Bluetooth®, including a list of compatible devices, please visit the **Find a Phone, Pair a Phone** section of mazda.co.uk/mzd-connect

PAIRING YOUR BLUETOOTH® PHONE OR AUDIO DEVICE

1. Turn on Bluetooth® on your phone or audio device and ensure it is visible to other devices
2. Select **Communication** from the Home screen
3. If no phone is currently connected to the system it will automatically prompt to connect a device. Select **Connect**
4. Ensure Bluetooth® is turned **ON** at the top of the menu
5. Select **Add New Device**
6. On your phone or audio device, perform a search for Bluetooth® devices
7. Select “**Mazda**” from the device list on your phone or audio device
8. If required, enter the pairing code shown on the vehicle display, or simply confirm that the code shown matches the one shown on the display by pressing **Yes** or **OK**
9. Press **Yes** on the car’s screen to confirm
10. Phone or device is now connected.



Please note:

Phones compatible with sharing contacts, call history or text messaging may require permission to be given on the phone for these functions. This will depend on the mobile device. Please refer to your phone's instruction manual for information.

To enable text message notifications when using an iPhone®, please ensure that **Show Notifications** is set to **On** within the Bluetooth® settings for the Mazda connection on your phone.

STEERING WHEEL-MOUNTED BLUETOOTH® CONTROLS



To make or accept a call.



To end or reject a call.



TALK button. Use to input a voice control command. Press again to skip voice guidance and speak next command.


MAKING/RECEIVING A TELEPHONE CALL

1. To make a call, either use the **TALK** button and say a command such as “Call Matt at home”, access the **Communication** menu, or you could access one of your favourite contacts from the **Favourites** menu (see next page)
2. To make a call via the **Communication** menu, select **Contacts** and scroll to the desired contact
3. Select the contact and desired telephone number if more than one number is available
4. To end a call, press the **End Call** button on the screen or steering wheel.

FAVOURITES

SETTING UP YOUR FAVOURITE RADIO STATIONS

1. Select **Entertainment** from the Home screen
2. Select the desired radio band - AM/FM/DAB (where fitted) - from the **Entertainment** menu
3. Using the **List**, **Scan** or **Tune** function, find the desired radio station




4. Press and hold the **Favourites** button to add current radio station to your favourites
5. Radio station is now saved and can be accessed at any time by pressing the **Favourites** button.

SETTING UP YOUR FAVOURITE CONTACTS

1. Ensure a compatible mobile device is connected via Bluetooth®
2. Press the **Favourites** button on the Multimedia Commander
3. Select **Communication Favourites** by moving the commander to the right, or if using the touch-screen, by selecting the **Communication** button within the favourites menu



FAVOURITES BUTTON



4. Select **Add/Edit Communication Favourites**
5. Select **Add New Contact**
6. Select desired contact from list
7. Contact is now saved and can be quickly accessed at any time by pressing the **Favourites** button
8. You can also add favourite contacts by pressing and holding the favourites button whilst a contact is selected in the Communication menu.

SETTING UP YOUR FAVOURITE NAVIGATION POINTS

Refer to the navigation pages in this guide for detailed instructions regarding your Mazda navigation system (where fitted).

CONNECTING TO INTERNET APPLICATIONS

AHA™ OR STITCHER™ APPLICATIONS



Before you can use either application, they must be downloaded to your Apple or Android mobile device and setup must be completed on your device before connecting to the vehicle. Both apps can be downloaded free of charge from your app store.

For more information regarding configuring Aha™ or Stitcher™ please view the how-to guides on mazda.co.uk/mzd-connect

USING THE AHA™ APP

1. Connect your Apple or Android device to the vehicle via Bluetooth®. App needs to be configured on device (see above)
2. Select **Entertainment** from the Home screen
3. Press the **Entertainment** button on-screen to access the source menu
4. Select **Aha**
5. Aha menu screen will be shown, select one of your radio presets.



USING THE STITCHER™ APP

1. Connect your Apple or Android device to the vehicle via Bluetooth®. App needs to be configured on device (see above)
2. Select **Entertainment** from the Home screen
3. Press the **Entertainment** button on-screen to access the source menu
4. Select **Stitcher**
5. Stitcher menu screen will be shown, select one of your playlists.



If another audio source is selected and then you return to either Aha™ or Stitcher™, the app will continue playing the preset or playlist that was last accessed.

Please note:

Internet applications require a valid data signal (3G/4G/Wi-Fi) and can use significant data volumes. Data costs and roaming charges may vary, please contact your network provider for more information. Ensure apps are shutdown on the device when disconnected from the car's audio system to prevent excess data usage. As a reference, listening to one hour of internet radio will use approximately 30 to 60MB of mobile data.

NAVIGATION SYSTEM

SETTING UP YOUR NAVIGATION SYSTEM

Your navigation system is ready to use straight away, however to ensure the best possible experience we recommend that you update your SD card to ensure you have the latest software and map data.

The navigation system comes with three years free map updates which commences after the navigation has been used for approximately 63 miles (100km).

UPDATING YOUR MAPS - REGISTRATION AND MAZDA TOOLBOX

1. On your personal computer navigate to **mazda.co.uk/mzd-connect/navigation**
2. Towards the top of the screen, click **Register** and follow the on-screen instructions to set up an account. You can subscribe to the newsletter to be kept up to date with future map updates
3. Once you have registered you will be sent an email to verify your email address. Please click the link in this email to confirm your account
4. Navigate back to **mazda.co.uk/mzd-connect/navigation** and login to the site using your chosen username and password by clicking **Login** at the top of the page
5. Select the MZD-Connect system by clicking **Choose**
6. Click **Download Toolbox** to the left of the page and then click **Download** to download the Mazda Toolbox
7. Once the Mazda Toolbox application is downloaded please launch the file and follow the on-screen instructions to install the Mazda Toolbox
8. Mazda Toolbox should now start and ask you to insert your SD card.




UPDATING YOUR MAPS - REMOVING THE SD CARD FROM THE CAR

1. To remove your SD card, ensure the car's ignition is OFF
2. Depending on your vehicle, the SD card slot will be located in your centre console in front of your gear knob, or within the front armrest storage box. Lift the flap covering the SD card slot
3. Gently push the SD card in, remove your finger and the SD card can then be pulled out.



Please note:

The SD card slot is only for genuine Mazda Navigation map SD cards. Do not insert any other SD cards into the vehicle as it may cause damage to the vehicle and/or the SD card.



UPDATING YOUR MAPS - DOWNLOADING AND INSTALLING MAP DATA

1. With the **Mazda Toolbox** application running, insert your Mazda Navigation SD card into your computer's SD card slot or SD card reader
2. You may be asked if you are happy to share anonymous GPS logs and usage information. Please **confirm** or **deny** this request
3. The application will then ask you to backup the data held on the SD card. This will ensure you are able to restore your navigation data in the event of data corruption
4. Once the backup is complete, click **Home** and login using the username and password that you registered previously
5. You may now be shown the main screen, to view available updates, click **Updates** on the left-hand menu. If no updates are available **Device** will be shown rather than **Updates**. Click on this to confirm your SD card data is up-to-date
6. If updates are available, click **Install** to download and install updates to the SD card
7. After confirmation the update has completed, the system will then inform you that your device is up-to-date. You can then remove the SD card from your computer and install back into the car.

Please note:

Ensure you have enough disk space to backup your SD card data and download any available map updates.

UPDATING YOUR MAPS - INSTALLING THE SD CARD INTO THE CAR

1. Ensure the car's ignition is OFF
2. Lift the flap covering the SD card slot
3. Gently push the SD card in, and when it clicks and remains in place, cover it with the flap
4. Turn the car's ignition on and press the **NAV** button to load the SD card.

Please note:

When installing the SD card into the car, ensure the lock switch on the SD card is in the unlocked position.

SETTING YOUR HOME LOCATION

MZD-Connect navigation allows you set a Home location which can be easily navigated to.










1. Press the **NAV** button, open the bottom menu and select **New Destination**
2. Select **Navigate Home**. The first time you do this, you will need to input your home location
3. Enter the Town or Postcode and a house number if required and press **Select Town Centre**
4. Your home location will be shown. To confirm, select **Set as Home**. Now whenever you select **Navigate Home**, you will be directed to this address.

CHANGING YOUR HOME LOCATION

1. Press the **NAV** button and then the **Favourites** button
2. Select **Home** and press and hold the main commander button for about 3 seconds. You will then be shown two options; **Edit Home** or **Delete Home**. Select the appropriate option.

NAVIGATION SYSTEM

NAVIGATION SCREEN OPTIONS

ICON	FUNCTION	PURPOSE
	Show Menu Bar	To open the bottom menu bar
	Hide Menu Bar	To close the bottom menu bar
	New Destination	To enter an address or favourite destination, or select a place of interest or location on the map
	Navigation Information	To switch to the navigation information screen displaying items such as traffic and GPS reception levels
	Cancel	To cancel an existing way point or route
	Places Nearby	To find places nearby
	Route Options	To display the route details and full length of route. Edit or cancel, pick alternatives or avoid parts of the route
	View Mode	To change the map mode (2D north up, 2D heading up, 3D)
	Settings	Adjust navigation settings

VOICE GUIDANCE

To repeat the last navigation instruction, press the **NAV** button on the Multimedia Commander. To mute voice guidance and any speed or warning alerts, ensure that the guidance volume is set to zero within the **Guidance Settings** menu found in the navigation **Settings** menu.

SETTING A ROUTE

1. Push the **NAV** button on the commander or touch-screen
2. Open the bottom menu and select **New Destination**
3. Select **Find Address**
4. Select **Town** to input a town or postcode



TO ENTER A NEW
DESTINATION

Please note:

Town is pre-populated based on your current location. Edit if you wish to search for a street address in another town. Postcodes can also be entered here.

5. Enter the **Street Name** and/or **House Number** if required. If a house number is entered, select the button on the bottom right of the screen to confirm
6. If you do not enter a house number, you can navigate to the centre of the street by selecting **Select Street**, or **Select Town Centre** to navigate to the centre of the town or postcode
7. Select **Navigate To**
8. The route display screen will show for 10 seconds before navigation begins unless you move to another option on the screen, in which case, press **Start** to begin navigation.

ALTERNATIVE ROUTES

After selecting **Navigate To**, there will be an option for **Route Alternative** which can be seen by scrolling down slightly. By default the fastest route is selected, however there are other routes available;

- Fastest Route (selected by default)
- Shortest Route
- Most Economical Route
- Easiest Route.

Once a choice of route has been made, press **back** to view the route screen and press **Start** to begin navigation



SETTING UP YOUR FAVOURITE DESTINATIONS

1. Press the **Favourites** button
2. Select **Navigation Favourites** by moving the commander to the right or if using the touch-screen by selecting the **Navigation** button within the favourites menu
3. Select **Add/Edit Navigation Favourites**
4. If a route is set, you can **Add Current Destination** as a favourite, otherwise you can only select **Add Current Location** or **Address From Contact** to add an address from a contact in your phonebook (when a compatible phone is connected via Bluetooth®)
5. Navigation point is now saved and can be quickly accessed at any time by pressing the **Favourites** button.
6. You can also add favourite locations by pressing and holding the favourites button whilst at the desired location within the navigation menu.

NAVIGATION SYSTEM

FIND PLACES

Search for points of interest such as airports or railway stations using the **Find Places** function.

1. Push the **NAV** button on the commander or touch-screen
2. Open the bottom menu and select **New Destination**
3. Select **Find Places**
4. Select **Filter By Name** to enter the name of a location if known, e.g. "Heathrow Airport" or to select a category of interest select **Set Category**. You can combine a name and category to be more specific in your search
5. Select the area you wish to search. **Around Here** is the default, or you can select **In a Town**, or if a route is already set, **Along Route** or **Around Destination**
6. Select **Search**
7. Select a desired location from the results to navigate to this point.

HISTORIC SPEED OVERVIEW

The system holds historic traffic information which can be accessed at any time. Historic speed data is also used when planning a route to take into account normal road conditions on your route at that time.



INFORMATION BUTTON

1. Push the **NAV** button on the commander or touch-screen
2. Open the bottom menu and select **Information** by pressing the **i** button on the bottom menu
3. Select **Traffic**
4. Select **Historical Speed Overview**.

You will then be shown a map of your current location with road speed depicted using a colour code. Green is a clear route, and red is a congested road. You can also view historical traffic at a certain time of the day for any day of the week by altering the settings using the bottom menu.

SMART HISTORY

The navigation system builds up a historical record of your previous journeys and can suggest destinations based on the time and day, previous routes and previous locations. For example if you travel to Manchester every Monday morning, Manchester will be top of the list of Smart History on a Monday morning. To access Smart History;

1. Push the **NAV** button on the commander or touch-screen
2. Open the bottom menu and select **New Destination**
3. Select **History**.

You are then able to view Smart History as well as chronological history, select a previous location and navigate to the location.

NAVIGATION CONNECTED SERVICES

CONNECTED SERVICES

Allows you access to a range of live data options within the navigation system

- Live traffic updates
- Live weather information
- Live fuel prices
- Advanced local search.



Connected Services are a subscription service. A 60-day free trial is included with your navigation system and commences the first time you connect the car to a Wi-Fi hotspot. After the free trial has finished you must purchase a subscription to continue using Connected Services. To do this, please refer to the instructions on page 15.

Please note:

To use live services a valid free trial period or paid subscription is required as well as a Wi-Fi connection for the data transfer.

SETTING UP A WI-FI HOTSPOT

Use your mobile device to create a Wi-Fi hotspot to use Connected Services. Every mobile device will have different settings, so please refer to the device's instruction manual for how to setup a Wi-Fi hotspot. The system can be connected to any available Wi-Fi hotspot.

CONNECTING THE CAR TO A WI-FI HOTSPOT

1. Select **Settings** from the Home screen
2. Select **Devices** from the top menu
3. Select **Network Management**
4. Ensure Wi-Fi connectivity is turned on
5. As long as the Wi-Fi network is made visible to all devices, then the name of the network should show on this screen. **Select the desired network**
6. Select **Password**
7. Enter the password - passwords are case sensitive
8. Select **Connect to**
9. Once a connection is made, the Wi-Fi symbol will show in white at the top of the screen showing the strength of the signal.



Upon first connecting to a Wi-Fi network and accessing the navigation menu the system will ask you to confirm you are happy to use Wi-Fi for data. Once a Wi-Fi connection has been made, the car will automatically connect to that network whenever it is available.

NAVIGATION CONNECTED SERVICES

ADVANCED LOCAL SEARCH

Works in a similar way to Find Places (see previous pages) but allows you to search from a much larger live database of local businesses and points of interest, also providing you the opportunity to telephone or navigate to their location.

1. Select **New Destination** from the bottom menu
2. Select **Local Search**
3. Search for any local business or point of interest, such as "Climbing Wall", for example
4. **Select the desired point** from the list of results and navigate to the location.

ACTIVATING LIVE TRAFFIC UPDATES

To use the live traffic function, it needs to be activated within the traffic settings:

1. Select **Navigation** from the Home screen or push the **NAV** button
2. Open the bottom menu and select **Settings**
3. Select **Connected Settings**
4. Ensure **Online Traffic** is selected
5. Go **back** to navigation settings
6. Select **Traffic Settings** and ensure **Online Traffic** is selected.



INFORMATION BUTTON

Live traffic will then be visible when setting a route or navigating to a destination. You can also view current traffic conditions by pressing the **i** button on the navigation bottom menu and selecting **Traffic**. Select **Current Traffic Overview** to view the traffic conditions around you or along a set route.

When live traffic is active and a route is set, detours can be offered if there is traffic along the route. If an alternative route becomes available, a notification will show on-screen asking if you wish to re-route around the incident and the time this could save you. To adjust the detour notification sensitivity or automatically accept detours, adjust the options within the traffic settings menu.

Please note:

Connected Services uses your mobile data via Wi-Fi connection with your mobile device. Connected Services uses approximately 30MB of data per month based on usage of six hours per day, five days per week. A valid data signal (3G/4G) and free trial period or paid subscription are required for Connected Services. Data usage and costs may vary, please contact your network provider for more information. Connected Services may not operate in areas of low signal strength.

ACTIVATING LIVE WEATHER UPDATES

1. Select **Navigation** from the Home screen or push the **NAV** button
2. Open the bottom menu and select **Settings**
3. Select **Connected Settings**
4. Ensure **Auto Download Weather** is selected.



Live weather will now be visible when setting a route or by accessing the Weather option within the navigation information menu by pressing the **i** button on the navigation bottom menu and selecting **Weather**. You will then have the option to search for weather along your route, at your destination or in a specific town.

ACTIVATING LIVE FUEL PRICES

1. Select **Navigation** from the Home screen or push the **NAV** button
2. Open the bottom menu and select **Settings**
3. Select **Connected Settings**
4. In the **Download Fuel Types** section select up to two fuel types.

Fuel prices will now be accessible within the navigation information menu by pressing the **i** button on the navigation bottom menu and then selecting **Fuel Prices**. You will then have the option to search along your route, around your destination or in a specific town.

Please note:

In petrol models, only Midgrade Gasoline (Premium Unleaded) and Normal Gasoline (Standard Unleaded) fuel prices are available in the UK. If neither of these are selected, no fuel prices will be shown.

PURCHASING A CONNECTED SERVICES SUBSCRIPTION

After the 60-day free trial has ended, a subscription will be required to continue using Connected Services:

1. Ensure you have registered at mazda.co.uk/mzd-connect/navigation and downloaded the **Mazda Toolbox** application as per the instructions on page 8 of this guide
2. With the **Mazda Toolbox** application running, insert your SD card into your computer's SD card slot or SD card reader
3. Click **Shop** on the left-hand menu
4. Connected Services subscription options will be shown. Select the desired subscription by clicking the respective icon and then **Add to cart**
5. Click **Go to Checkout** to confirm, then **Checkout** and then **Verify Your Order** to enter or confirm your billing address
6. Click **Payment** to select your payment method and enter your payment details
7. Once payment has been made, your subscription is added to your SD card and you should see a screen stating "**Your device is up to date**". You can then remove the SD card from your computer and install back into the car.

To view your purchase, click **Home** on the left-hand menu and then **Transaction History**



ACTIVE DRIVING DISPLAY (WHERE FITTED)

ADJUSTING THE DISPLAY

Please note:

DO NOT ADJUST THE HEAD-UP DISPLAY MANUALLY.
This may damage the display.

1. Ensure your seat is set to your driving position
2. Select **Settings** from the Home screen
3. Select **AD-Disp** from the top menu
4. Select **Height**
5. Use either the touch-screen or Multimedia Commander to slide the bar left or right to select a suitable height for the head-up display.



DEACTIVATING THE DISPLAY

1. From within the **AD-Disp** settings menu (see above), select **Active Driving Display** and untick the box. **Please note this only deactivates the display rather than folding away the screen.**
2. To re-activate the display, tick the box.

Please note:

The Active Driving Display will re-activate each time the vehicle's engine is started.

ACTIVATING TURN-BY-TURN NAVIGATION ON THE DISPLAY

1. From within the **AD-Disp** settings menu (see above), select **Navigation** and tick the box to display turn-by-turn navigation instructions. This will then show the next turn and distance on the head-up display whenever a route is set
2. To deactivate turn-by-turn navigation from the display, untick the box.

MORE INFORMATION ON MZD-CONNECT INFOTAINMENT

For more information on any of the functions explained in this guide, or any part of the connectivity or infotainment system, please visit mazda.co.uk/mzd-connect where you can view easy-to-follow how-to guides of some of the most common functions.

mazda.co.uk 03457 48 48 48

Part Number: 810079226 February 2015