

Model: 175-8734

Command Tower Enclosure Kit


Tripod Accessory

Timber Strike™

TREE STANDS

WARNING

- When hunting from a treestand, falls can occur at any time which can cause injury or death.
- Please do not return this product to the Menards. Call BIG DOG TREESTANDS toll free (1-866-387-2002) for quick replacement of any damaged or missing parts.



Please inspect the shipping carton for evidence of damage or that it may have been opened before you received it. Then inspect your product carefully. Compare it to the image on the product label and the picture illustration in your instructions. You must check and tighten all bolts before each use. If for any reason you are not satisfied with the product, do not use it until the problem is solved or corrected.

PACKING LIST:

A	1	Enclosure Cover	Part # TTKC-100
B	1	Top Frame	Part # TTKTF-100
C	2	Support Frame	Part # TTKSF-100
D	4	6mm x 1 - 1/8" Cap Bolt	Part # 7025
	4	6mm x 1 - 5/8" Bolt	Part # 1013
	4	6mm Locknut	Part # 2010

ASSEMBLY INSTRUCTIONS

1. Note: Insure to install the cage assembly/cover at ground level. Refer to Tripod instructions and warnings for proper installation/procedures of raising/assembly of the unit prior to each use and installation of Tower Kit(s). Bolt (2) SupportFrame(s) (Item C) to the left/right side of the Top Frame (Item B) using (4) 6mm x 1-5/8" bolts and locknuts. Tighten All bolts/locknuts securely.
2. Insure the Shooting Rail Supports are assembled correctly on the tripod unit. The short welded tubes on the side are pointed toward the center of the platform and the weld-nuts are pointed to inside of the platform area. Insert the cage assembly into the welded tubes on the shooting rail support tubes. Slide the unit down till it rests on top of the shooting rail. Next, insert the Cap Bolts (Item D) into the weld nuts on the shooting rail support tubes. Insure not to tighten down so the cage will slide up/down. Cap Bolts should be facing toward the platform.
3. Next, slide the cage assembly halfway out and tighten down the cap bolts. Next, slide the cover over the cage assembly till the zip area on top is flat. Rotate the fabric till the entry zipper is facing the entry steps into steps. Unzip front entry and roof section of the enclosure unit.
4. The enclosure unit can be adjusted full up position and fully down position if the top is unzipped. Insure to lock cage assembly with cap bolts at desired position.

WARNING

- Insure ground under the Foot Plates of Tripod is firm and level. Inspect all parts/sections to insure all are secured and free of damage or wear before leaving the ground.

SAFETY WARNINGS

Please read this instruction for safe hunting



ALWAYS

- Read and Understand ALL instructions and warning pages thoroughly before using your Fall Arrest System, treestand, ratchet/stabilizing straps, and climbing device prior to each use. Replace suspected or damaged components with only factory authorized parts and components.
- Practice using the treestand and FAS at ground level until comfortable and understand the product usage.
- Insure that your Fall Arrest System, treestand, tree straps, and climbing devices are in good working order without defects, wear, broken or missing parts before each use. This inspection includes the following prior to each use: Retightening all bolts and nuts, inspecting hardware and all components made of fabric (seat, straps or ropes) and all metallic/non metallic items for excessive wear or damage.
- Wear a Fall Arrest System attached to the tree from the time you leave the ground until the time you return to the ground. Keep the tether strap between you and the tree as short as possible to reduce the distance in case of a fall. Keep the linesman strap tight on the tree while you ascend or descend from the tree. The FAS tether must be tight while in a seated position.
- Practice with your stand and Fall Arrest system at ground level before using them in an elevated position.
- Step down into the center of the platform from your climbing aide while being attached to the tree with your FAS. Position your fixed position stand below your climbing aide to allow you to step down into the platform.
- Store your Fall Arrest System, treestand, straps, all instructions/warnings, and climbing device in a cool/dry location away from sun light, weathering, sharp objects and any type of wildlife. NOTE: Wildlife may chew on straps/seats while the stand is not in use and may cause serious damage. Check ALL straps and seats prior to each use. Review all warnings/instructions annually.
- Hunt with a friend/partner to ensure that someone knows your hunting location as well as the time you are due to return home or to camp.
- Take your time and move slowly at all times that while you are in or climbing to or descending from your treestand. Use 3 Point Climbing Technique while ascending or descending.
- Use (3) or more people to set-up any treestand unless instructed to have more people present. Use a min. 10" diameter straight/healthy tree on all treestands.
- Use a hoist line to pull fixed position stand(s) up to the positioning height below the end of the climbing aide.
- Understand the intended use for the product and warnings and only use this Big Dog Product as instructed.
- Have a cell phone, walkie-talkie, or two-way radio on your person for emergency purposes and to inform others of your hunting location.

NEVER

- Leave the ground without wearing your FAS Harness and being attached to the tree from the time you leave the ground until you return to the ground. Failure to wear FAS or FAS not attached to the tree at any time could result in serious injury or death.
- Climb with your weapon. Ensure that the firearm/bow is unloaded with its barrel pointed toward the ground when raising or lowering it to your stand. Always use a safe hoist/lift system on the opposite side of the tree from which you climbed.
- Climb with anything on your back or anything that will restrict your movement or will interfere with FAS Harness.
- Exceed the manufacturer's weight limit for the product, including your body weight plus the weight of your clothing/gear.
- Attempt to adjust the chains or straps of any treestand while standing on the platform, while secured to the tree.
- Use this product if you are under the influence of alcohol, mind-altering frugs, have any heart problems, dizzy spells, afraid of heights, phsically impaired to use product safely, feeling ill, nauseous, or dizzy.
- Climb/Use a tree that is diseased, dead, has dead or broken branches, or loose bark.
- Stand on the seat/footrest/shooting rail/armrest or rely on any branches for support or means of securing.
- Exceed/modify the suggested manufactures hunting height for any product.
- Jump, bounce, lean-out from, lean against shooting rails or sleep in any treestand for any reason, at any time.
- Leave any treestand attached to the tree more than (2) two weeks. Tree growth will stress the straps and/or chains to the point of a possible failure that could result in serious bodily injury or death.
- Use your stand during a thunderstorm/raining or other adverse weather conditions that have the potential to produce lightning, high winds, or if snow/ice is present on the platform or steps.
- Use a tree stand for any purpose other than hunting. Do not use on utility poles or any other man made structures.
- Loan or let anyone use the treestand or FAS Harness without reading and understanding all product instructions and safety warnings of the product(s).
- Make any modifications to this product. Any modifications will void warranties and relieve Big Dog Treestands Inc. from all liabilities.

WARNING

- Failure to read and follow these safety warnings and instructions could result in serious bodily injury or death.
- You must replace all straps (ratchet, cinch, stabilizing) every year. Use only Big Dog replacement straps and parts. Any other straps or parts will be viewed as a modification to the product. Any modification will void the warranties and relieve Big Dog Treestands Inc. from all liabilities.
- Always Inspect Treestand/Straps/FAS throughly prior to each use. Do not use if ANY damage/wear is suspected/present.
- It is recommended that you oil/lubricate all hardware as needed, or at least annually. It is recommended that you replace all hardware (nuts/bolts/clips/ straps/ropes) and seats on your tree stand every two years or sooner if inspection finds it necessary.
- Failure to use a Fall Arrest System (FAS) could result in serious bodily injury or death.