

# Form Feed and Cut the Plotter Paper

When installing a new roll of plotter paper, the taped end of the paper must be form fed and cut. Use **the LCD on the plotter** to accomplish this.



1) Press the **TOP** button.



2) Press the **down-arrow** button to select **Roll**.



**Roll** is the 2<sup>nd</sup> of four icons on the right side of the LCD.



3) Press the **ENTER** button to choose **Roll**.



4) Press the **down-arrow** button to select **Form Feed & Cut**.



5) Press the **ENTER** button to choose **Form Feed & Cut** which will cut a **three-inch strip** of paper from the roll.

