



myPDFmanuals

You can read the recommendations in the user guide, the technical guide or the installation guide for HP COMPAQ DC7800 SMALL FORM FACTOR PC. You'll find the answers to all your questions on the HP COMPAQ DC7800 SMALL FORM FACTOR PC in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual HP COMPAQ DC7800 SMALL FORM FACTOR PC
User guide HP COMPAQ DC7800 SMALL FORM FACTOR PC
Operating instructions HP COMPAQ DC7800 SMALL FORM FACTOR PC
Instructions for use HP COMPAQ DC7800 SMALL FORM FACTOR PC
Instruction manual HP COMPAQ DC7800 SMALL FORM FACTOR PC

Installing Microsoft Windows 2000 on
Selected HP Business Desktop PCs



Introduction	2
System Requirements and Prerequisites	2
System Requirements	2
System Prerequisites	2
Drivers and Deliverables	3
Installing the Operating System and System Hardware	3
For More Information	5



[You're reading an excerpt. Click here to read official HP COMPAQ DC7800 SMALL FORM FACTOR PC user guide](http://mypdfmanuals.com/dref/859853)
<http://mypdfmanuals.com/dref/859853>

Manual abstract:

11.6230 Reav A (SoftPak SP36604) Intel PRO/1000 NIC Drivers 9.8.20.0 Rev A (SoftPak SP36743) Microsoft Windows XP SP2 Universal Audio Architecture Update (Q888111) 1.00 Rev A (SoftPak SP30628) Installing the Operating System and System Hardware Important: Back up all user data prior to installing Microsoft Windows 2000. 1. Boot to a Windows 2000 Professional CD, and follow the on-screen instructions for installation. Install Service Pack 4 if necessary. 3 Important: Service Pack 4 must be installed for driver installs to be successful 2.

Run the latest DirectX Installer redistribution package from www.microsoft.com. Follow the directions to expand the files to the hard drive. Run DXSetup.exe from this location, and allow the system to reboot. Run the SoftPak for the Intel PRO/1000 NIC and allow it to extract the files to the hard drive. Open Device Manager, and expand Other devices. Double-click on the entry for the Ethernet Controller. Click the Reinstall Driver button. Click Next. Click Next. Select only Specify a location then click Next. C:\swsetup\SP36743\PRO1000\Win32. 3. 4. 5. 6. 7. 8.

9. 10. Browse to the NIC driver location for Win32. For example, 11. Select el000325 (*inf) then click Open. 12. Click OK. 13. Click Next. 14. Click Finish. For the remaining drivers on Table 1, run the associated SoftPak and follow the on-screen directions to complete the installation. Important: If you have an Internet connection, go to This will require a reboot. www.microsoft.com/windowsupdate and install the critical patches. 4 For More Information To learn more about business desktops, contact your local HP sales representative, or visit our Web site at www.hp.com. © 2007 Hewlett-Packard Development Company, L.

P. The information contained herein is subject to change without notice. The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein. Microsoft and Windows are U.S. registered trademarks of Microsoft Corporation..



[You're reading an excerpt. Click here to read official HP COMPAQ DC7800 SMALL FORM FACTOR PC user guide](http://mypdfmanuals.com/dref/859853)
<http://mypdfmanuals.com/dref/859853>