

Linksys AM300 Quick Configuration

This User Guide provides step-by-step instructions on how to configure a Linksys AM300 modem using the quick configuration utility.

Why is this task performed?

This user guide will assist you in configuring the Linksys – AM300 modem using the quick configuration utility.

Troubleshooting

If after completing this user guide you are unable to get online a factory reset of the modem may be required. Please refer to the Linksys AM300 user manual for instructions on how to complete a factory reset.

What tools are used to complete the task?

Linksys AM300 Modem, Linksys AM300 User Manual, Ethernet/USB cable and a PC.

Linksys AM300 Quick Configuration




Instructions

In the *Internet Explorer* screen complete the following steps:

- 1 In the Address field enter :
Ethernet:/USB = 192.168.1.1

Note: USB drivers must be installed first before proceeding with this userguide.

- 2 Click .





Linksys AM300 Quick Configuration



Instructions

In the *Log In* screen, complete the following steps:

- 1 In the Username field enter: admin.
- 2 In the Password field enter: admin.
- 3 Click .



The screenshot shows a 'Log In' form with the following elements:

- A title bar labeled 'Log In'.
- A message: 'Please log in to continue.'
- A 'Username:' label with a text input field containing 'admin'. A blue circle with the number '1' is next to the label.
- A 'Password:' label with a password input field containing six dots. A blue circle with the number '2' is next to the label.
- A 'Login' button at the bottom right. A blue circle with the number '3' is next to the button.

Linksys AM300 Quick Configuration



Instructions

In the *Setup* screen, complete the following steps:

- 1 From the Encapsulation drop down menu select RFC 2364 PPPoA.
- 2 Ensure the VPI is set at 8 and the VCI is set at 35 from the Virtual Circuit ID: field.
- 3 Select the VC radio button from the Multiplexing field.
- 4 From the DSL Modulation: field select Auto.
- 5 Enter the username in the Username field.
- 6 Enter the password in the Password field.

Refer to the Settings Page on our website for the username format.

Refer to the Settings Page on our website for the password format.

LINKSYS®
A Division of Cisco Systems, Inc. Software Version: 1.09

Setup ADSL Modem **AM300**

Setup Security Applications & Gaming Administration Status

Basic Setup | DDNS | Advanced Routing

Internet Setup

ADSL Settings

Encapsulation: **1** RFC 2364 PPPoA

Virtual Circuit ID: **2** 8 VPI (Range 0 ~ 255)

3 35 VCI (Range 0 ~ 65535)

Multiplexing: **4** ☐ LLC ☒ VC

DSL Modulation: **5** Auto

PPPoA Settings

User Name: **6** bless@mysoul.com.au

Password: **6** [REDACTED]

☐ Keep Alive: Redial Period 0 Min. (Range 0~500)

☒ Connect on Demand: Max Idle 20 Min. (Range 1~1000)

Optional Settings (required by some ISPs)

Host Name: [REDACTED]

Domain Name: [REDACTED]

Basic Setup

ADSD Settings: The values for this section must match those of your ADSL Internet connection. Please check with your Internet Service Provider to verify the correct settings.

PPPoA Settings: Please enter the PPPoA username and password that was provided by your Internet Service Provider.

Linksys AM300 Quick Configuration



Instructions

Scroll down the *Setup* screen, complete the following steps:

1 From the Timezone drop down menu select the time zone applicable to the state you are in.

2 Click **Save Settings**.

Network Address Server Settings (DHCP)

Local DHCP Server: ☒ Enabled ☐ Disabled

Start IP Address: . . .

Number of Addresses:

IP Address Range: **192.168.1.2 to 192.168.1.254**

Client Lease Time: Hour Min (Less than or equal to 72 hours)

Time Setup

Set Time Zone

☐ Automatically adjust clock for daylight saving changes

Time zone: 1

Configure Time Server (NTP)

☒ Enable Automatic Time Server Maintenance

Primary Server:

Secondary Server:

Current Date and Time: **08/01/2003, 00:02:58**

2 **Save Settings** **Cancel Changes**

CISCO SYSTEMS

Linksys AM300 Quick Configuration



Instructions

In the *Settings are successful* screen, complete the following step:

- 1 Allow up to 25 seconds for the previous page to load.

Settings are successful.

- 1 You will be returned to the previous page after 25 seconds.

Linksys AM300 Quick Configuration



Instructions

In the *Status* screen, complete the following steps:

1 Click on Status.

2 Ensure the PPP Login field is displayed as Up.

This indicates the modem has authenticated.

If the Up field hasn't displayed after a few minutes perform a factory reset (Refer to manual) and complete this userguide again.

If this doesn't resolve the issue contact our Customer Care team.

You have completed the Linksys AM300 Quick Configuration Userguide and are now ready to connect to the internet.

Status

ADSL Modem AM300

Setup Security Applications & Gaming Administration **1** Status

Modem Local Network

Modem Information

Software Version: **1.09**
ADSL Version: **6.0.2.0**
Boot Code Version: **0.01**
MAC Address: **00-16-B6-FB-A3-7D**

DSL Status

DSL Status: **UP**
DSL Modulation Mode: **Auto**
DSL Path Mode: **FAST**
Downstream Rate: **1536 Kbps**
Upstream Rate: **256 Kbps**
Downstream Margin: **22 db**
Upstream Margin: **24 db**
Downstream Line Attenuation: **38**
Upstream Line Attenuation: **48**
Downstream Transmit Power: **7**
Upstream Transmit Power: **0**
LOS Errors: **0**

Internet Connection

2 PPP Login: **Up**
Internet IP Address: **220.240.177.101**
Internet Netmask: **255.255.255.0**
Internet Gateway: **203.220.49.241**

Disconnect

Modem

This page gives the status of Modem like Software version, Ethernet Mac, ADSL Link Status, System Uptime, Internet IP Address etc.