



(Picture 1)



(Picture 2)



(Picture 3)



(Picture 4)

EDCNOVA

Instructions for Set-up & Closure

Step 1) Unfold the container until two sides are 90° to each other. (See *picture 1*)

Step 2) Locate lift loop on the inner fold. (See *picture 1*)

Step 3) Place your foot on Nova bottom that is resting on the ground. With your hand, pull the lift loop, mentioned in Step 2, until the sides are completely open. (See *picture 2*)

Step 4) Pull the top cover out and around the outside of the container so the interior cavity is easily accessible. (See *picture 3*)

Step 5) Turn Nova on its side to reach the liner inside the bag. Open the liner, and place inside of Nova. Drape the excess portion out and around the container's outer walls for easy access to the opening. (See *picture 3*)

Step 6) Fill the container with material.

Step 7) Once filled, twist the liner 3 times clockwise and fold over the twisted section. Wrap the enclosed zip tie around the folded section of liner. Tighten and secure the zip tie.

Step 8) Fold the top closure flaps over the top of the bag. Locate the top tie downs and side loops. Insert the tail of each tie down through its respective side loop. Secure the ties downs with an overhand knot. (See *picture 4*)

To Reorder Nova Bags: Please call Questar at (330) 966-2070