Elevator Safety Program PO Box 14470 Salem, Oregon 97309 Tel: (503) 373-1298

Fax: (503) 378-4101

# Hydraulic Elevator Checklist

### Passenger & Freight Elevators

Multi-Car Acceptance Inspection Checklist

References

ASME A17.1, 2004 – Effective 4/1/2005 A17.2, 2001 – Effective 1/1/2003

Oregon Structural Specialty Code 2003 – Effective 10/1/2004 Oregon Electrical Specialty Code 2005 – Effective 4/1/2005

NFPA 72, 2002; Fire Alarm Systems NFPA 13, 2002; Sprinkler Systems

Note: Potential code violations are not necessarily restricted to this checklist.

The comments used in this checklist give direction only and are not intended to circumvent actual code language. Please refer to the appropriate standard as necessary to clarify any code issues that may arise during this inspection.

The codes referenced in this checklist are applicable to the elevator installation as of the effective date of the elevator safety code. If an electrical or structural permit was issued prior to 4/1/2005, the previous addition of the code may be used to resolve code conflicts providing a copy of the electrical and/or structure permit is obtained for verification.

While the Elevator Safety Program does not directly regulate the building code, it is permissible to question code issues and request clarification or validation from the local building department. Do not require any corrections unless supported by the local building department in such cases.

Site Name:		Code Date	e:/
Elevator ID: Car #1:	Car #2:	Car #3:	<u>-</u>
1 <sup>st</sup> Inspection	2 <sup>nd</sup> Inspection	3 <sup>rd</sup> Inspection	4 <sup>th</sup> Inspection
/	/	/	/
Arr: :	Arr: :	Arr: :	Arr: :

### HYDRAULIC PASSENGER & FREIGHT ELEVATORS

#### **ASME A17.1 2004**

Sa	fety Te	st Data					ed Hydi						metric	or imper	ial mea	asure	ments-Metric	: 🔲 Imperi	al 🔲)
	Speed: (fpm)	Slide:	ed: Min. Min.			<b>/A</b>		Турє	Type of Safeties N/A ☐  A B C ☐ ☐ ☐		R	x./Min. Oil Buffer unby Return N/A		Net   Platform   Rated Spee   M/s or (f   m² (ft²)					
Car Designation		Swit If >.75 (150 f	m/s		Speed s fpm		Thru [lbs.)	Slide mm (in.)			Pull Out mm (in.)		Cwt.	Car	Max seco	. 90 onds	Passenger   Freight	] ] Empty Car	
	ated eed	Car	Cwt	Car	Cwt	Car	Cwt	Car	Cwt	Ca	r C\	vt	900 mm (36")	610 mm (24")	Car	Cwt		I Empty Car	Full Load
Ca	ır 1																	Up	Up
m/s(	fpm)																	Dn	Dn
Ca	ır 2																	Up	Up
m/s(	fpm)																	Dn	Dn
Ca	ır 3																	Up	Up
m/s(	fpm)																	Dn	Dn
		[			rement				Illumi Minimu			1					Runn Take nominal m	ing Clearand neasures throu	
	ar nation	Door Press. 135 N (30 lbs)	Do Clos Spe m/ (ft/	sing eed —	Door T (ADA Car	iming req.) Hall	Hall 100 lx - 10 ftc	E- Light 2 lx 0.2 ftd	50	Car lx - ftc	Pit 100 lx - 10 ftc		M/R 200 lx - 19 ftc	Floor Passing Tone Min. 20 db	Emero Ala 80-	rm	Sill Clearance 13/19-38 mm (½" – 1 ½") or (¾" – 1 ½")	Car to H/W mm (in.)	Car to Cwt. Minimum 50 mm (2") N/A
Car 1	Front						eet												
Oai i	Rear						Enter on Next Data Sheet												
Car 2	Front						xt Dai												
Cai Z	Rear						n Ne												
Car 3	Front						nter o				_								
Cai 3	Rear						ū												

### HYDRAULIC PASSENGER & FREIGHT ELEVATORS ASME A17.1 2004

	Safety Test Data Sheet 2 – Direct & Roped Hydraulic Elevators (indicate metric or imperial measurements-Metric 🗌 Imperial 🗍)															
				Refug	e Space		Ор	erating Pre	essures kpa	(PSI)	Notes/Co	mments:				
		Т	ор		Botto	m		WP ÷ I	PR = %							
De	Car signation	n	Ht. 1100 nm 3 in.)	600 i 450 i	mm x 1220 n mm x 900 mr	nm x 600 mm n x 1100 mm	Empty Car	Working Pressure (WP)	Pressure Relief (PR)	% Max. 150% of WP						
Ca	ar 1			xx												
Car	2			<u> </u>	x	_ x										
Car	3				x	x										
								<u> </u>	<u> </u>		1	222				
	. et	- nd		- rd	Land	ling Illumii	nation Le	vels - Ind	dicate:	Lx or	ftc (1 l)	k = .929 ft	C)	- th	th	th
	1 <sup>st</sup>	2 <sup>nd</sup>		3 <sup>rd</sup>	4 <sup>th</sup>	5 <sup>th</sup>	6 <sup>th</sup>	7 <sup>th</sup>	8 <sup>th</sup>	9 <sup>th</sup>	10 <sup>th</sup>	11 <sup>th</sup>	12 <sup>th</sup>	13 <sup>th</sup>	14 <sup>th</sup>	15 <sup>th</sup>
1																
2																
3																
Co	mments															

AREA	REQ.	COMMENTS	Cars 1-3				
INSIDE CAR	A17.1 (A17.2)	A17.2 item numbers appear below A17.1 req. numbers only if comments are found in A17.2 for acceptance inspections.	Check the box for the corresponding car				
DOOR OPERATION							
Door Reopening Device	2.13.5.1	Doors must stop and reopen Front Rear					
Door Closing Force	2.13.4.2.3	Cannot exceed 135 N (30 lbs.) (see 2.13.3.1).	Enter readings on data sheet				
Door Kinetic Energy (see application pg. 2)	2.13.4.2.1	Not to exceed 10 J (7.37 ft-lbf) on average closing speed.     Maximum: 23 J (17 ft-lbf) at any point in the code zone distance.	Enter readings on data sheet				
Door Closing Speeds (Typically freight elevators)	2.13.3.4.5	1) Bi-parting doors; maximum 0.3 m/s (1 ft/s) 2) Vertical doors; maximum 0.6 m/s (2 ft/s)	N/A				
Unlocking of Doors  Power Opening of Doors	2.13.2	1) Opening not to exceed 450 mm (18") from floor. 2) Must open within 75 mm (3") from floor. 3) Shall only occur in the leveling zone					
Restricted Opening of Doors- Anti-egress device	2.12.5	<ol> <li>Anti-egress lock (zone lock)</li> <li>Door opening not to exceed 100 mm (4")</li> </ol>	N/A				
Vision Panels	2.14.2.5	Vision panels must comply with the following:  1) Max. of 0.1 m <sup>2</sup> (144-in <sup>2</sup> ).  2) Not more than 150mm (6") on one side.  3) Marked wire glass or laminated glass only.	N/A				
Glass Door Panels	2.14.5.8 (1.11.3)	Glass panels must be: 1) Minimum 60% of visible door area as viewed facing the hoistway door. 2) Laminated glass only. 3) Min. 14.29 mm (9/16") thick.	N/A				
Car Door or Gate	2.14.4.5	1) Distance from car door to hoistway door:  a) Swing H/W door & Car Gate; 100 mm (4")  b) Swing H/W door & Car Door; 140 mm (5½")  c) Sliding H/W door & Car Door/gate; 140 mm (5½")					
Closed Position of Car Doors	2.14.4.11	Maximum between door and jamb; 50 mm (2")					
Freight Elevator Door Types	2.14.6.1	Door must be of the following configuration: 1) Class A Loading; Vertical or horizontal 2) Class B or C Loading; Vertical only	N/A				
Gate Switch	2.26.2.15	Not accessible from inside car					
OPERATION & FIXTURES							
Emergency Stop Switch & Emergency Stop Switch Audible Signal.	2.27.1.2	When an emergency stop switch (2.26.2.5) is provided, an audible signaling device shall be provided. The audible signaling device shall	N/A 🗆				
E-stop switch not allowed in		a) have a rated sound pressure rating of not less than 80 dBA nor greater than 90 dBA at 3 m (10 ft);					
passenger elevators.		b) respond without delay after the switch has been activated;					
		<ul><li>c) be located inside the building and audible inside the car and outside the hoistway; and</li><li>d) for elevators with a travel greater than 30 m (100 ft), be</li></ul>	N/A □				
		duplicated as follows: i) one device shall be mounted on the car; and ii) a second device shall be placed at the designated level.					
In Car Stop Switch (passenger elevators)	n Car Stop Switch 2.26.2.21 Passenger Elevator						

Completed for: Car 1-0 2-0 3-0 Page 3 of 36 Hydraulic Elevator Checklist 2004 Multi-car Group.doc

Car Enclosure	A17.1 (A17.2)	COMMENTS	CARS 1-3
Operating Control Devices ADA Requirements *Refer to ICC/ANSI A117.1- 2003 see attached ADAAG information and figures. See A17.1, Table 2.26.12.1	2.26.1.1 2.26.12 407.4.6* (1.3 & 1.5)	Car Operating Station; 1) Push button operation 2) Braille (all COP buttons and controls)  a) Located at main floor car call. 3) Alarm button: 890 mm (35") from floor 4) Highest call button maximum height: 1370 mm (54") w/parallel approach	
Leveling Accuracy	2.26.11(a)	Leveling accuracy required to be ± ½" (± 13 mm)	
Minimum Door Widths Note: A 42" opening for C/O	407.4.1*	Location Clear Side to Back to Back to Opening Side Return Door	
doors is not yet mandatory. If 36" opening is provided it	N/A 🗌	C/O 1065 mm 2030 mm 1295 mm 1370 mm (42-in.) (80-in.) (51-in.) (54-in.)	
complies with the OSSC.	N/A 🗌	S/S 915 mm 1725 mm 1295 mm 1370 mm (36-in.) (68-in.) (51-in.) (54-in.)	
	N/A 🗆	Any (36-in.) (54-in.) (80-in.) (80-in.)	
	N/A 🗌	Any (36-in.) (60-in.) (60-in.) (60-in.)	
Car Position Indicators; Visual and Audible	407.4.9.1* 407.4.9.2*	1) CPI: a) minimum 13 mm (½") in height b) above door or COP c) direction indicator 2) Audible Indicators	N/A
Hall and Car Lanterns Visual & Audible Signals  For Destination Oriented systems, see A117.1.	407.2.2.1* 407.2.2.2* 407.2.2.3*	1) Hall:  a) provided at each landing b) indicate direction  2) Car:  a) Must be visible from the hall call buttons  3) Both:  a) Centered 1830 mm (72-in.) from floor b) Minimum 64 mm (2½-in.) along vertical C/L  4) Audible signals shall:  a) Sound once for up; twice for down b) Audible tones @ 1500 Hz c) Verbal annunciators @ 300 to 3000 Hz d) Minimum of 10 dBA above ambient e) Maximum of 80 dBA	
Door Delay (car calls)	407.3.5*	Elevator doors shall remain fully open in response to a car call for 3 seconds minimum.	Enter Measurements on Data Sheet
Handrails	505*	Handrails are no longer required. Where provided they shall comply with Section 505 of ANSI A117.1.	
GFI 15 & 20 Amp Receptacles	NEC 620-85	All in-car receptacles <i>may</i> be GFCI protected or be of the GFCI type	N/A 🗌
Sill Running Clearance	2.5.1.4	1) Clearance 13-38 mm (½ - 1½ in.) 2) Corner Poster, 19-38 mm (¾ - 1½ in.)	Enter Measurements on Data Sheet

Completed for: Car 1-0 2-0 3-0 Page 4 of 36 Hydraulic Elevator Checklist 2004 Multi-car Group.doc

Car Enclosure	A17.1 (A17.2)	COMMENTS	CARS 1-3
Sills and Car Floor	(1.4)	Check that landing sills are substantially flush with the floor surface of the landings and the sill does not present a tripping hazard.	
		a) Changes in level up to 1/4 in. (6 mm) may be vertical and without edge treatment.	
		b) Changes in level between 1/4 in. (6 mm) and 1/2 in. (13 mm) must be beveled; and	
		c) Changes in level above 1/2 in. (13 mm) must be ramped.	
Car Numbering (Multiple Cars)	2.29.1	1) Minimum 13.0 mm (½") high on COP	
Car Lighting & Accessories Enter ftc measurements on the data sheet .	3.14 (1.5.3)	<ol> <li>Min. 50 lx (5 ftc) @ sill (passenger)</li> <li>Min. 25 lx (2.5 ftc) @ sill (freight)</li> <li>Minimum of 2 lamps must be provided.</li> <li>E-light min. 2 lx (0.2 ftc) @ COP (not required on freight)</li> </ol>	Enter measurements on data sheet
	620.22>	elevators)	
	620.54>	6) Car AC/heating Units (when provided)	N/A
		provided:	N/A 🗆
		if:	
Car Enclosure Materials (Passenger Elevator)	2.14.2 (1.12.3) 2.14.3	Metal, laminated glass or meet ASTM E84, UL 723 or NFPA 255; (carpet) ASTM E 648     Laminated glass must comply with:	
Ventilation                Fan provided but not required.	2.14.2.3	2) ANSI Z97.1 or 16 CFR 1201, Sect. 1201.4  1) Natural Ventilation Openings a) Not more than 300 mm (1') from platform b) Must reject 25 mm (1" ball); 50 mm (2" on freight) c) Above 1825 mm (6'), must reject 50 mm (2") ball d) Total area 3½% of inside floor area e) No "straight-through" vent openings  2) Forced Ventilation	
Platform Net Inside Area (Passenger Elevators only) Not applicable to freight elevators	2.16.1.1 (1.16.3) ANSI A117.1	<ol> <li>Ensure platform area does not exceed maximum allowed for rated load:</li> <li>Minimum size car with side opening doors cannot be less than 1727 x 1295 mm (68"w x 51"d)         (ADA req.; equates to about a 2000-lb. cap. car)</li> <li>Minimum size car with center opening doors can not be less than 2032 x 1295 mm (80" w x 51" d) (ADA req.; equates to about a 2500-lb. cap. car)</li> </ol>	N/A ☐ Enter Measurements on Data Sheet

Completed for: Car 1-0 2-0 3-0 Page 5 of 36 Hydraulic Elevator Checklist 2004 Multi-car Group.doc

<u></u>		<u>,                                      </u>	
Car Enclosure	A17.1 (A17.2)	COMMENTS	CARS 1-3
In-Car Inspection Operation	3.26.2	In-car Inspection operation:	N/A 🗌
(where provided)	(2.26.1.4)	1) Shall operate the car at no more than 0.75 m/s (150 fpm.)	
		Shall be of the continuous pressure type.	
		3) Transfer of control located in the car marked clearly "on-	
		off" 4) Transfer switch keyed or behind locked panel	
		5) May not operate when car top inspection station is	
		activated	
Emergency Exit	2.14.1.5.1	1) Min. 0.26 m <sup>2</sup> (400 <sup>2</sup> ") & min. 400 mm (16") on any side:	
	8.4.4.1.1	2) Be equipped with a five-pin keyed lock unlike any other	
		key in building. May be keyed alike with the hoistway	
		access key when provided (refer to 2.12.7)	
	2.14.1.5.1(d)	<ol> <li>Clear access must be maintained for opening in a dropped ceiling to escape hatch.</li> </ol>	
Intercom	2.27.1.1.4	An intercom or telephone capable of being activated from	ппп
	(Oregon	a point outside the elevator shall be provided and be	
	amendment)	located at a readily accessible point outside the hoistway	
		that is available to emergency personnel. One master	
		control station may be used to connect all elevators under	
		common group control.	
		2) The device shall be within sight of the elevators served. (see 2.27.1.1.4(a)-(d) for additional requirements).	
Oregon Amendment to 2.27.1.1.4:		(See 2.27.1.1.4(a)-(u) for additional requirements).	
	capable of being	activated from a point outside the elevator shall be provided and be lo	cated at a readily
accessible point outside the	e hoistway that is	available to emergency personnel. One master control station may be u	
		evice shall be within sight of the elevators served.	
		ncy personnel within the building to establish two-way voice communication shall be established without any intentional delay and shall not require	
		override communications to outside of the building.	e intervention by a
		once established, shall be disconnected only when emergency personn	el outside the car
terminates the call.			
		ication has been established, the visual indication [see 2.27.1.1.3(c)] we extinguished when the two-way communication is terminated.	ithin the car shall
		proprieted with or adjacent to the two-way voice communication outside the	e car Instructions
shall conform to 2.27			
		required to be dedicated. However, the failure or use of any single devi	ce, including other
		ne telephone line shall not render the elevator telephone inoperative.	
Capacity Plate	2.16.3.1	Located in conspicuously in car.	
Identification Numbering	2.29.1	1) Minimum 13 mm (½") high on COP.	
(w/multiple cars in bldg.)	2 27 7	1) Next to Dhage II quitab :	
Phase II Operation Sign	2.27.7	1) Next to Phase II switch.; 2) Minimum 3 175 mm (1/8") high letters	HHH

Hydraulic Elevator Checklist 2004 Multi-car Group.doc Page 6 of 36 Completed for: Car 1-0 2-0 3-0

legible.

Plates shall be of such material and construction that the

letters and figures stamped, etched, cast, or otherwise applied to the faces shall remain permanently and readily

The height of the letters and figures shall be not less than
a) 6 mm (0.25 in.) for passenger elevator capacity plates
b) 25 mm (1 in.) for freight elevator capacity plates

3 mm (0.125 in.) for data plates

Observe ride, slow down and stop

Last Updated: 8/22/05

Material and Marking of


Plates.


Car Ride

2.16.3.3

(1.19.3)

Car Enclosure	A17.1 (A17.2)	COMMENTS	CARS 1-3
Data Plates  ☐ Existing	2.16.3.2	The data plate shall be located on the car crosshead, or inside the car for underslung elevators having no crosshead.	
	2.16.3.2.1	Information Required on Plates      a) Capacity plates shall indicate the rated load of the elevator in kilograms or pounds or both (see Nonmandatory Appendix D), and, in addition, this plate or a separate plate shall indicate	
		b) the capacity lifting one-piece loads where the elevator conforms to 2.16.7	
	2.16.3.2.2	c) for freight elevators designed for Class C2 loading, the maximum load the elevator is designed to support while being loaded or unloaded [see 2.16.2.2.4(c)]  3) Data plates shall indicate	
	2.10.3.2.2	a) the weight of the complete car, including the car safety and all auxiliary equipment attached to the car	
		b) the rated load and speed c) the wire rope data required by 2.20.2.1 d) the name or trademark of the manufacturer and year manufactured	
		e) rail lubrication instructions (see 2.17.16)	
Access Panels	2.14.2.6	Nonremovable sliding or swing panels shall be permitted for access to the car or hoistway transparent enclosures for cleaning purposes.     Such panels or doors shall	N/A 🗌
		<ul> <li>a) if hinged, open only into the car</li> <li>b) be provided with cylinder-type locks, having not less than a five-pin or a five-disc combination, or a lock that provides equivalent security, arranged so that they can be unlocked with a key from the car side, and the key</li> </ul>	
		shall be Group 2 Security (see 8.1) c) be openable by hand from the hoistway side d) be self-locking e) be provided with a device arranged so that the panel must be in the closed and locked position (see 2.26.2.31) before the elevator can operate	
		f) have a bottom edge a minimum of 1 070 mm (42 in.) from the floor in cases where the adjacent hoistway wall is more than 140 mm (5.5 in.) from the car enclosure or where there is no adjacent hoistway wall.	





Hydraulic Elevator Checklist 2004 Multi-car Group.doc Last Updated: 8/22/05 Page 7 of 36

Completed for: Car 1-0 2-0 3-0

	A17.1	ASIVIE A17.1 2004	
Car Enclosure	(A17.2)	COMMENTS	CARS 1-3
Telephone / communication	2.27.1.1.1	1) A two-way communications means between the car and a	
Device		location in the building, that is readily accessible to	
Note: Oregon amendment	0.07.4.4.0	authorized and emergency personnel shall be provided.	
2.27.1.2 requires that a	2.27.1.1.2	2) When the two-way communications location in the building is	
communication device be		not staffed 24 h a day, by authorized personnel who can	
installed in each elevator		take appropriate action, the means of two-way	
and be capable of		communications shall automatically be directed within 30 s	
connecting to a 24-hour		to an additional on- or off-site location, staffed by authorized	
location. The device must be	2.27.1.1.3	personnel, where an appropriate response can be taken.  3) The two-way communication means within the car shall	
ADA compliant in accessible	2.27.1.1.3	comply with the following requirements:	
elevators. Dedicated	2.27.1.1.3(b)	a) A push button to actuate the two-way communication	
telephone lines are not	2.27.1.1.3(0)	means shall be provided in or adjacent to a car	
required, but the failure or		operating panel. The push button shall be visible and	
use of any single device		permanently identified as "HELP." The identification	
connected to same		shall be on or adjacent to the "HELP" button. When the	
telephone line cannot render		push button is actuated, the emergency two way	
the elevator telephone		communication means shall initiate a call for help and	
inoperative.		establish two-way communications.	
	2.27.1.1.3(c)	b) A visual indication on the same panel as the "HELP"	
		push button shall be provided, which is activated by	
		authorized personnel, to acknowledge that two-way	
		communications link has been established. The visual	
		indication shall be extinguished when the two-way	
	0.07.4.4.0(-1)	communication link is terminated.	
	2.27.1.1.3(d)	c) The two-way communication means shall provide on	
		demand to authorized personnel, information that identifies the building location and elevator number and	
		that assistance is required.	
	2.27.1.1.3(e)	d) After the call acknowledgement signals are sent	
	2.27.1.1.0(0)	[2.27.1.1.3(c)], the two-way voice communications shall	
		be available between the car and authorized personnel.	
	2.27.1.1.3(f)	e) The two-way communications, once established, shall be	
		disconnected only when authorized personnel outside	
		the car terminate the call.	
	2.27.1.1.3(g)	f) The two-way communication means shall not use a	
		handset in the car.	
	2.27.1.1.3(h)	g) The two-way communications shall not be transmitted to	
		an automated answering system. The call for help shall	
		be answered by authorized personnel.	
	2.27.1.1.3(i)	h) Operating instructions shall be incorporated with or	
		adjacent to the "HELP" button.	

Car Enclosure	Req.		Comments	Cars 1-3
Freight Car Enclosure	2.14.3.1			N/A 🗆
		1.	Must be of metal without openings to a height of 1830 mm (72").	
		2.	Must extend to at least 150 mm (6") either side of counterweights (when provided)	
		3.	Perforations above 1830 mm (72") shall reject a 38 mm (1") diameter ball.	
(Freight Flavotor)> N/A	2.16.2.2.1	1)	☐ Class A: General Loading 240 kg/m² (50 lb/ft²)	
(Freight Elevator)> N/A ☐	2.16.2.2.1	1) 2)	☐ Class B: Motor Vehicle Loading 145 kg/m² (30 lb/ft²)	
	2.16.2.2.3(a)	3)	☐ Class C1: Industrial Truck Loading (static load during	
	2.10.2.2.3(a)	3)	loading & unloading does not exceed rated load)  a) 240 kg/m² (50 lb/ft²)	
	2.16.2.2.3(b)	4)		
	2.10.2.2.3(0)	7)	loading & unloading may exceed rated load)	
	2.46.2.2.2(a)	E)	a) 240 kg/m² (50 lb/ft²) ☐ Class C3: Loading with Heavy Concentrations	
	2.16.2.2.3(c)	5)	a) 240 kg/m² (50 lb/ft²)	
Freight Elevator Signs	2.16.5.1.1	1)	"CLASS A LOADING. ELEVATOR TO BE LOADED OR	
2.46.5.2 Minimum 42 mm (1/")			UNLOADED MANUALLY OR BY MEANS OF HAND	
2.16.5.2 Minimum 13 mm (½")			TRUCKS ONLY. NO SINGLE PIECE OF FREIGHT OR	
high lettering.			SINGLE HAND TRUCK AND ITS LOAD SHALL EXCEED	
		2)	KG (LB)." "CLASS B LOADING. THIS ELEVATOR DESIGNED TO	N/A □
		2)	TRANSPORT MOTOR VEHICLES HAVING A MAXIMUM	
			GROSS WEIGHT NOT TO EXCEED KG	
			( LB)."	
		3)	"CLASS C1 LOADING. THIS ELEVATOR DESIGNED TO	N/A □
		0)	TRANSPORT LOADED INDUSTRIAL TRUCK. MAXIMUM	
			COMBINED WEIGHT OF INDUSTRIAL TRUCK AND	
			LOAD NOT TO EXCEED KG ( LB)."	
		4)	"CLASS C2 LOADING. THIS ELEVATOR DESIGNED	N/A
		,	FOR LOADING AND UNLOADING BY INDUSTRIAL	
			TRUCK. MAXIMUM LOADING AND UNLOADING	
			WEIGHT WHILE PARKED NOT TO EXCEED	
			KG ( LB). MAXIMUM WEIGHT	
			TRANSPORTED NOT TO EXCEED KG ( LB)."	
		5)	"CLASS C3 LOADING. THIS ELEVATOR DESIGNED TO	N/A
		,	TRANSPORT CONCENTRATED LOADS NOT TO	
			EXCEEDKG (LB)."	
	2.16.5.1.2	6)	For elevators not permitted to carry passengers, the sign	N/A □
			shall read: "THIS IS NOT A PASSENGER ELEVATOR.	
			NO PERSONS OTHER THAN THE OPERATOR AND	
			FREIGHT HANDLERS ARE PERMITTED TO RIDE ON	
			THIS ELEVATOR."	T
	2.16.5.1.3	7)	For freight elevators permitted to carry passengers (see	
		'		
	2.16.5.1.3	7)	9 1 9 1	N/A 🗆

Completed for: Car 1-0 2-0 3-0 Page 9 of 36 Hydraulic Elevator Checklist 2004 Multi-car Group.doc

MAC	HINE ROOM	Req.			COMMENTS	N	I/R 1-3	
Access to an		2.7.3 >	1		Clear and unobstructed passage to door			
Machine Roo	om	2.7.3.2 >	2	)	Access Across Roofs:		<u>.</u> N/A 🔲	
					Swing door and platform from top floor to roof.			
Keys shall be					b) Hatch type doors must have assisted opening	_		
	cessible only to				(springs, hydraulics, cwt. etc.)		HH	
	and emergency				c) Illuminated access route (eff. 10/1/99)		$\sqcup_{L/L}$	
personner. (C	Group 2 Security)	2.7.3.2.2	> 3	)	If roof slopes over 15°:a) Walkway to M/R door must be provided not less than		N/A 🔲	
					600 mm (24") wide.		⊔ ⊔	
		2.7.3.3 >			b) Down side must have 1100 mm (43") handrail.			
		2.7.3.3.1			Access to differing levels of M/R and from roof to M/R and			
					machinery spaces:		N/A 🔲	
		2.7.3.3.2	>		a) If level is > 200 mm (8"); non-combustible ladder or			
					stair.			
		2.10			b) If level is > 900 mm (35"), a stair must be provided			
		0.7000			equipped with handrails.			
		2.7.3.2.2	<b>`</b>		c) Railings on upper level to 1070 mm (42") high.	IН		
		2.7.3.3.3			d) Ladders must comply with ANSI A14.3.		HH	
		2.1.3.3.3			<ul> <li>e) Railings to comply with ANSI A1264.1.</li> <li>f) Stairs must be between 30° and 50° from horizontal.</li> </ul>			
		2.7.3.3.4	,		f) Stairs must be between 30° and 50° from horizontal. g) Platform or floor shall be provided at top of access	ΙH	HH	
		2.7.0.0.1			stair.			
		2.7.3.3.5	>		i) If door swings outward; minimum 600 mm (24")			
					plus door swing.	_		
					ii) If door swings inward; minimum 750 mm (30")			
Angle of	Rise	Tread Run	2.7.3	3.3	Means of Access. (amended)		N/A 🗌	
Stair	Rise	rreau Run	2	.7.:	<b>3.3.4</b> Permanent, noncombustible stairs shall be provided			
☐ 30° 35'	165mm (6½")	280mm (11.0")	and o	con	form to following regulations for industrial stairs regarding			
					ridth, run and rise, and handrails.			
☐ 32° 08'	170mm (6¾")	273mm (10¾")			ir shall be a minimum of 560 mm (22 in.) in width. Fixed			
☐ 33° 41'	178mm (7.0")	267mm (10½")			shall be not less than 30° nor more than 50° from			
					al. A uniform combination of rise and tread dimensions e permitted to be used. The following table gives			
☐ 35° 16'	184mm (7¼")	260mm (10¼")			ible run and rise dimensions that will produce a stair that			
☐ 36° 52'	190mm (7½")	255mm (10.0")	comp	olie	s with this requirement.			
☐ 38° 29'	197mm (7¾")	248mm (9¾")			r treads and platforms shall be reasonably slip-resistant. d railings shall be provided on both sides of any stair with			
☐ 40° 08'	200mm (8.0")	240mm (9½")	a wid	dth	of 1100 mm (43 in.) or less and with four or more risers.			
☐ 41° 44'	210mm (8¼")	235mm (9¼")			rways wider than 1100mm (43 in.), only one handrail is I, preferably on the right hand side, descending. Railings			
☐ 43° 22'	216mm (8½")	228mm (9.0")	shall	СО	mply with Section 2.10.			
☐ 45° 00'	222mm (8¾")	222mm (8¾")			here the stair to the machine room or machinery space is egress stair, the stair must comply with the requirements			
☐ 46° 38'	228mm (9.0")	216mm (8½")			uilding code. heck box in the column, "angle of stair", indicate the			
☐ 48° 16'	235mm (91/4")	210mm (8½")	clos	est	angle of the installed stairway.		· · ·	
☐ 49° 54'	240mm (9½")	200mm (8.0")	If the	e ai	ngle is outside this range, indicate the actual angle.>		ne nearest legree)	
Access to an	` '	3.7.2	1. \	Wit	hin 6 m (20') of hoistway if unless elevator can be seen			
Machine Roc		Ore.			n machine room entrance.			
☐All elevato	ors in same M/R	Amend.	2.	Cle	ar and unobstructed passage to door.			
	<u>nine spaces an</u>							
	ices are not ye							
	code; alternat							
	r exceptions ar	<u>'e</u>						
required.		1				<u> </u>		

Access to Overhead & 2.7.3.4   1) Openings in M/R floors must have either doors or 1100 mm (43") high railings around opening.	
	N/A 🗌
2.7.3.4.3 2) Where complete bodily entry not necessary:	N/A 🗌
a) Sized for access and maintenance of equipment located	$\sqcup \sqcup \sqcup$
therein. b) Maximum 600 x 600 mm (24" x 24")	
c) Lockable access doors/panels.	HHH
2.7.3.4.1 3) Machine rooms & overhead spaces.	N/A
a) M/R doors shall be a minimum 1830 mm (72") high and	
750 mm (30") wide.	
b) Overhead-space: 750 mm x 750 mm (30 in. x 30 in.)	
i) Self-closing and self locking	
c) Provided with door sign (see next block for	
requirements).	N/A
d) Overhead emergency stop switch required.	
Exceptions to Stairways 2.7.3.3.6 1) Vertical ladders with handgrips shall be permitted to be used in lieu of stairs under the following conditions:	N/A 🗌
a) Access to an overhead machinery space is less than	
2440-mm (96-in.) from floor level and access to the	
overhead machinery space is from within the machine	
room; or	N/A 🔲
b) In existing buildings where installation of a stair would	
require alterations to structural elements or the stair	
would obstruct an egress corridor.	
2) Fixed ladders, when installed, shall be provided with a	
means for safely transporting tools and maintenance materials to and from the upper machinery level.	
a) The means shall be operable from the top and bottom of	
the ladder.	
3) Where the access door or panel is through the side of the	N/A 🗌
machinery space, the ladder shall terminate at a landing	
conforming to ANSI A14.3, Section 6.	
Machine Room Door & Sign 2.7.3.4.5 "AUTHORIZED PERSONNEL ONLY - Storage or installation of	
Ore. equipment not pertaining to the elevator is prohibited"  Amend. 1) 9.5 mm (3/8") high letters @ 1524 mm (60")	
Amend. 1) 9.5 mm (3/8") high letters @ 1524 mm (60") 2) Door is to be a min. 750 mm (29.5") wide by 2030 (80") in	
height	
3) Self-closing and self-locking	
4) If rating is required check for labeling	
5) Keys to be kept on premises – Security Group 2	
Headroom 2.7.4.1 1) Minimum 2130 mm (84") clear throughout entire machine	
(2.2.3) room. Some minor exceptions may be permitted in corners	
and close to walls.  Enclosure 2.7.1.1 1) Check for proper construction rated or non-rated. Taped	
Enclosure 2.7.1.1 1) Check for proper construction rated or non-rated. Taped sheet rock.	
2.7.1.2 2) Enclosure and M/R door must be equivalent fire rating to the	
hoistway.	
Ventilation 2.7.5.2 1) Ventilation must be:	
(2.6.3) a) Natural; or	
b) Mechanical	
c) Temperature range must be maintained to:	
i) Manufacturers Specs: or (Oregon amendment); or ii) Between 13° C - 38° C (55° F- 100° F)	
3006.2 2) Where applicable on roped hydraulic elevators:	N/A 🗌
a) Openings in M/R floors for hoist ropes cannot be any	
larger than needed for the hoist ropes plus 50 mm (2-	
in.).	

MACHINE ROOM	Req.		COM	MENTS		M/R	2 1-3
Housekeeping	8.6.4.8.1	1) M/R shou	ld be clean				
Pipes, Ducts & Wiring	(2.8) 2.8.2.1	No unrela	ted pipes, ducts	or wiring			1 🗆
Tipes, Buots a willing	(2.8.3)			ass from the mach	nine room to the		
Shunt Trip Device	2.8.2.3.2		R or top of H/w is	sprinklered:			N/A 🗌
(See testing section on this		1) Must be lo	cated in M/R	•			
checklist)		functions	are retained.	vith disconnect a	_		
Guarding of Exposed Equip	2.10.1			and sheaves shall			
Equipment Numbering All cars in same machine room	2.29.1 620-51	1) Required room.	where multiple	driving machines	are in the same		N/A 🗌
or space?	020-51		cting means.				╡Ħ
Yes ☐ No ☐; there are		3) Controller					5 🗇
M/R/space(s).		4) Pump uni					
Illumination	2.7.5			floor level; evenly			
Enter Measurements on				e that will not allo	w lamps that will	шц	$\sqcup$
Data Sheet	620.23		ess than minimur n a dedicated bra			ПГ	пП
	020.20	,		the load side of a C	SFCI		5 🖯 🖠
	2.7.5.1			sy reach of strike			
Main Line Disconnect	NFPA 70 620-51	Fused disposition.	sconnect or circ	uit breaker, locka	ble in the open		
	(2.11.3)		ocated within 600 OAR 918-305-0	0 mm (24") of the (250)	open side of the		
				aker location (620-			
Car Lighting Disconnect	NFPA 70			vator Controlling 1	20vac to car		
	620-53		branch circuit mu ent protection req				╡╠
	(2.11.3) 620.22	3) Overcuite	in protection req	ulleu III W/K			
Utilization Equipment	NFPA 70	1) Ensure th	at disconnecting	means is located i	n M/R.		
(Equipment may include intercoms that are not part of the elevator control circuit)	620.25			tion is provided fo			
Electrical Clearances	110-26 (2.12.3)	Minimum greater.	width: 30" or widt	th of controller, whi	chever is		
Ensure electrical clearances			height from floor:				
are properly maintained in		Condition	1	2	3		
front of all electrical panels and disconnects located in the		0-150v	900 mm (36")	900 mm (36")	900 mm (36")		
M/R.		151-600v	900 mm (36")	1000 mm (42")	1200 mm (48")		
Working Clearances	2.7.2.2.1 Ore. Amend.		610 mm (24") nce and repairs.	on all sides requ	iring access for		
Controller wiring, fuses and grounding.	2.8.1	Ensure pringrounded		nstalled and equip	ment is properly		
grounding.			conductors for lig	htning protection	systems allowed		
				down conducto	or not allowed		
		4) Art. 350-		al conduit is pern	nitted under the		
		a) Flex (i) 1	conditions: can not exceed 1 Note: Liquid tight nm (72")	830 mm (72") flex allowed in le	ngths over 1830		
		b) Ratin	g can not exceed	l 20 amps load listed for groundin	g		

MACHINE ROOM	Req.	COMMENTS	Cars 1-3
Electrical Assembly*	2.26.4	Certification to CSA B44.1/ASME A17.5; Provide cert. or listing	
Approved Testing Labs:		number:	
		(Label #1:)	
If unit is not labeled, it must be		(Label #2:)	
field certified by a testing lab or		(Label #3:)	
replaced with properly certified unit unless otherwise authorized		(Label #0.	
by Salem.		UL- CSA- ETL- MET- Other:	
Hydraulic Power Unit	3.24.1.1	Working Pressure must appear on plate	ппп
Trydradiio i ower omi	(2.16.3)	Liquid level indicator;	
	3.24.3.3	a) Must be of the type that can be checked without	
		removing covers	
	3.24.3.1	3) Covers and venting	
Pressure Tanks	3.24.4	1) Unless covered by A17.1, must conform to ASME Boiler	N/A 🗌
	(2.16.3)	and Pressure Vessel Code	
Control Valve	3.19.4.3-4	1) Ensure valve is of the type that comprises a check valve and	
Type:	(2.15.3)	manual lowering.	
#1:		2) Manual lowering speed limited to 0.10 m/s (20 fpm)	$\sqcup \sqcup \sqcup$
#2:			
#3: Flexible Hoses and Fittings	3.19.3.3	1) H/P hoses shall:	N/A 🗌
Labeling must contain:	(2.17.3)	a) Not be installed in hoistways or through walls.	
Mfg. name or trademark;	(2.17.5)	b) Be wire reinforced as specified by SAE J5 17D	HHH
Type of hose & fitting;		c) Withstand 5 times working pressure	HHH
Min. factory test pressure;		d) Must be provided with a line overspeed valve (refer to	吊吊吊
Min. bending radius;		3.19.4.7)	
Date of installation;		e) Marked with a replacement date no more than 6 years	
Inspection procedure.	8.6.5.6	from installation	
		f) Labeled as indicate in the first column	
Tank Fastenings	8.4.11.6	Must be prevented from being overturned	
Supply Line and Shut Off	3.19.4	Fittings and piping and valves shall:	
	Ore. Amend	a) Located in M/R (Note: Pit shut-off also required).	
	(3.19.4.2)	b) Have a safety factor of 5	
		<ul> <li>c) (Mfg. psi x mfg. SF/5 = allowable working psi)</li> <li>d) Cannot be cast iron, malleable iron or certain brass or</li> </ul>	HHH
		bronze materials.	Ц Ц Ц
GFI 15 & 20 Amp Receptacles	NFPA 70	Must be of the GFCI type.	
or roa 20 / imp recopiacios	620-85	1) Made be of the of type.	
Fire Extinguisher (Class ABC)	8.6.1.6.5	Located within easy reach of the access door	ППП
	(2.7)	Current dated inspection tag.	
	, ,	(Note: size of extinguisher is not specified in code).	
Machine Room Inspection	3.26.2		N/A 🗌
Control (where provided)	(2.26.1.4.4)	1) Shall operate the car at no more than 75 m/s (150 fpm.)	
		Actual fpm.	
		2) Shall be of the continuous pressure type.	
		3) Transfer means must be located in the machine room.	
		Clearly marked "on-off"     Must not operate if either in-car or car top inspection	
		<ol> <li>Must not operate if either in-car or car top inspection control is active or in door bypass mode</li> </ol>	
Code Data Plate	8.9.1	Located on mainline disconnect or controller.	
Gode Bata Flate	0.5.1	Indicate code for inspections and tests.	HHH
		State ID tag may be used to supply such information	吊吊吊
Installation Permits	OAR	1) To be located in the M/R in clear view & not to be removed	- 市市市
	918-400-	from site until passed.	
	400	•	
Limited Elevator Journeyman	ORS	Name:	
Licensee and/or Electrician	479.630(6)	<del>                                   </del>	
TM's work must be signed-off by		License #:	
licensed journeyman <b>Permits</b>			
must be <u>signed!</u>			

Completed for: Car 1-0 2-0 3-0 Page 13 of 36 Hydraulic Elevator Checklist 2004 Multi-car Group.doc

MACHINE ROOM	Req.	COMMENTS	Cars 1-3
--------------	------	----------	----------

### NFPA 13 (2002) Installation of Sprinkler Systems 8.14.5 Elevator Hoistways and Machine Rooms

- **8.14.5.1** Sidewall spray sprinklers shall be installed at the bottom of each elevator hoistway not more than 0.61 m (2-ft.) above the pit floor.
- **8.14.5.2** The sprinkler required at the bottom of the elevator hoistway by 8.14.5.1 shall not be required for enclosed, noncombustible elevator shafts that do not contact combustible hydraulic fluids.
- **8.14.5.3** Automatic sprinklers in elevator machine rooms or at the tops of hoistways shall be of ordinary or intermediate-temperature rating.
- 8.14.5.4 Upright or pendent spray sprinklers shall be installed at the top of elevator hoistways.
- **8.14.5.5** The sprinkler required at the top of the elevator hoistway by 8.14.5.4 shall not be required where the hoistway for passenger elevators is noncombustible and the car enclosure materials meet the requirements of ASME A17.1, Safety Code for Elevators and Escalators.

Note: Hoistway wall construction that contains wood framing is considered combustible despite a 1 or 2-hour rating. In addition, hydraulic fluid is considered combustible despite a relatively high ignition temperature.

#### NFPA 72 (2002) National Fire Alarm Code

- 6.15.3 Elevator Recall for Fire Fighters' Service
- **6.15.3.1** System-type smoke detectors or other automatic fire detection as permitted by 6.15.3.7 located in elevator lobbies, elevator hoistways, and elevator machine rooms including machine space, control room, and control space used to initiate fire fighters' service recall shall be connected to the building fire alarm system.
- **6.15.3.2** In facilities without a building fire alarm system, these smoke detectors or other automatic fire detection as permitted by 6.15.3.7 shall be connected to a dedicated fire alarm system control unit that shall be designated as "elevator recall control and supervisory panel", permanently identified on the control unit and on the record drawings. Unless otherwise required by the authority having jurisdiction, only the elevator lobby, elevator hoistway, and the elevator machine room smoke detectors shall be used to recall elevators for fire fighters' service.
- **6.15.3.3** Unless otherwise required by the authority having jurisdiction, only the elevator lobby, elevator hoistway and the elevator machine room smoke detectors or other automatic fire detection as permitted by 6.15.3.7 shall be used to recall elevators for fire fighters' service.
- **6.15.3.4** Each elevator lobby, elevator hoistway, and elevator machine room smoke detectors or other automatic fire detection as permitted by 6.15.3.7 shall be capable of initiating elevator recall when all other devices on the same initiating device circuit have been manually or automatically placed in the alarm condition.
- **6.15.3.5** A lobby smoke detector shall be located on the ceiling within 6.4 m (21-ft.) of the centerline of each elevator door within the elevator bank under control of the detector.

Exception: For lobby ceiling configurations exceeding 4.6 m (15 ft.) in height or that are other than flat and smooth, detector locations shall be determined in accordance with Chapter 5.

Note: The OESC defines an elevator lobby as the area in front of the elevator where persons normally wait for the elevator. This distance is typically a radius of 4-6 ft. from the center of the elevator door. This distance may vary depending on site conditions. However, if the detector is in compliance with 6.15.3.5 the installation is acceptable.

- **6.15.3.6** Smoke detectors shall not be installed in unsprinklered elevator hoistways unless they are installed to actuate the elevator hoistway smoke relief equipment.
- 6.15.3.7 If ambient conditions prohibit installation of automatic smoke detection, other automatic fire detection shall be permitted.
- **6.15.3.8** When actuated, each elevator lobby, elevator hoistway, and elevator machine room smoke detector or other automatic fire detection as permitted by 6.15.3.7 shall initiate an alarm condition on the building fire alarm system and shall visibly indicate, at the control unit and required remote annunciators, the alarm initiation circuit or zone from which the alarm originated.

Indicate Condition	Description	Door Rating	Machine Room
1 🗆	Machine room shares a common wall, floor or ceiling with the hoistway; Penetrations are not fire-stopped; and Door opens to exterior of building.	N/A	1 or 2 hr.
2 🗌	Machine room is located above the roof level.	N/A	N/A
3 🗌	Machine room shares a common wall, floor or ceiling with the hoistway; and Penetrations are properly fire stopped.	N/A	N/A
4 🗌	Machine room does not share a common wall, floor or ceiling with the hoistway.	N/A	N/A
5 🗌	Machine room shares a common wall, floor or ceiling with the hoistway; Penetrations are not fire-stopped; and door opens to interior of building.	1 or 2 hr.	1 or 2 hr.

Hydraulic Elevator Checklist 2004 Multi-car Group.doc Page 14 of 36 Completed for: Car 1-0 2-0 3-0

Last Updated: 8/22/05

MACHINE ROOM	Req.	COMMENTS	Cars 1-3
Hydraulic Cylinders Perform this test if there is any indication of settling. Otherwise this test may be omitted until required during periodic maintenance and testing.	(2.36)	1) This test should be performed after the relief valve test in Item 2.31 and the flexible hose test in Item 2.34. Cylinders that cannot be inspected visually should be tested in the following manner with no load in the car. Mark the location of the car at any convenient position. Open the disconnect switch for 15 min. Note the position of the car platform with respect to the reference mark. A change in car position that cannot be accounted for by visible oil leakage, valve leakage, or temperature change of the oil indicates a leak of the cylinder or in the underground piping and a need for further inspection, tests, or repairs.	
Pressure Switch	(2.37)	See Testing Section	
Relief Valve	(2.31)	See Testing Section	
Roped Water Hydraulic Elevator  Existing Equipment	(2.38)	1) Check the condition of the rod at the thread end, which is where the bolt and nut are against the plunger. This should be done on the bottom and top ends. It is very common for the rod to break where the thread and nut end are against the plunger packing thread.	
Comments:		one are against the planger passing arroad.	

Completed for: Car 1-0 2-0 3-0 Page 15 of 36 Hydraulic Elevator Checklist 2004 Multi-car Group.doc

TOP OF CAR & HOISTWAY	Req.	COMMENTS	Cars 1-3
Sheetrock Screws Penetrating into Hoistway (Oregon amendment)	2.1.1.3 (3.10)	<ol> <li>Sharp protrusions in areas that require maintenance shall be removed or guarded. (Usually around jambs and door panels).</li> </ol>	
(crogon amonamony		<ol> <li>Verify multiple hoistways are constructed in compliance with the building code. Measure the running clearances between cars including equipment attached to the car.</li> </ol>	
		Projections should be properly beveled or otherwise protected.	
		<ol> <li>For elevators with no top emergency exit installed in unenclosed hoistways, determine that all landings are provided with either hoistway entrances or emergency doors.</li> </ol>	
Hoistway Construction  Rated	2.1.1 (3.10.3)	If hoistway is fire rated, ensure that there are no open penetrations through interior surface of walls.	
☐ Non-rated ☐ Existing	(= = = ,	2) Ensure that elevator door entrance frames are properly interfaced with wall construction.	
Hoistway Smoke Control	2.1.4 (3.11)	<ol> <li>Must be in accord with the OSSC.</li> <li>Pressurization is allowed, but airflow cannot impinge on the operation of the elevator.</li> </ol>	
		<ol> <li>Check that means to prevent the accumulation of smoke and hot gases in case of fire is in accordance with the requirements of the building code.</li> </ol>	
Hoistway Ventilation 8 m (25') or more measured from the bottom landing to the	Chapter 30 3004 3004.3	<ul> <li>Area of vents.</li> <li>1) Except as provided for in section 3004.3.1, the area of the vents shall not be less than 3½ percent of the area of the</li> </ul>	
underside of the hoistway ceiling Indicate actual size of vent:		hoistway; nor  a) less than 3 square feet (0.28 m2) for each elevator car, and	
☐ H/W #1ft²		b) not less than 3½ percent nor less than 0.5 square foot (0.047 m2) for each dumbwaiter car in the hoistway, whichever is greater.	
☐ H/W #2 ft²		<ul> <li>Of the total required vent area, not less than one- third shall be of the permanently open type unless all vents activate upon detection of smoke from any of</li> </ul>	
H/W #3		the elevator lobby smoke detectors.  2) Exceptions: If the building is fully sprinklered, vents are	
If vent is not provided when site conditions appear to require		only required for the following occupancy groups:  a) R-1 – Residential	N/A 🗆
same, contact the local building department for consultation.		i) Boarding houses, hotels/motels (transient) b) R-2 – Residential	N/A 🗆
☐ Existing Equipment		<ul> <li>i) Apts. convents, dormitories, fraternities, monasteries, vacation timeshare, hotels/motels (non-transient)</li> </ul>	
		c) I-1 – Institutional	N/A 🗆
		d) I-2 – Institutionali) Hospitals, nursing homes, mental hospital, detox centers, outpatient clinics	N/A 🗆
Wiring ( Refer to NFPA 70 Table 400)	NFPA 70 620-11	Hi-temp door lock wire     Elevator Traveling Cable	
Use Listed Traveling Cables. SO Cord not legal for travelers!	620-21	3) Flame retardant wiring throughout	

TOP OF CAR & HOISTWAY	Req.	COMMENTS	Cars 1-3
Counterweights (Where provided)	8.4.7 3.33.3.2	<ol> <li>Seismic requirements apply to elevators with rated speed of 0.75 m/s (150 fpm) or greater.</li> <li>Hydraulic Elevators</li> </ol>	N/A 🗌
☐ Existing Equipment	(3.33)	a) Verify the top counterweight clearance and bottom counterweight runby.	
		<li>b) Also, verify that a counterweight buffer is not provided.</li>	
		<ul> <li>If a counterweight is provided and the space below the hoistway is not permanently secured against access, verify that a counterweight safety is provided.</li> </ul>	
Number of cars in Hoistway (this should be checked by the local building inspectors and plan review department)	Chapter 30 3003.1	<ul> <li>1) Predicated on total number of cars in the building:</li> <li>a) All cars may be in same hoistway. (≤ 3 cars in bldg.)</li> <li>b) Must be in two separate hoistways. (= 4 cars in bldg.)</li> <li>c) No more than four in same hoistway. ≥ 5 or more cars in bldg.</li> </ul>	
GFI 15 & 20 Amp Receptacles	NFPA 70 620-85	Must be of the GFI type and shall not extinguish car top work light.	
Top of Car Operating Station	3.26.2 (2.26.1.4)	Top-of car inspection operation shall conform to 2.26.1.4.1 and the following:	
	,	a) A stop switch (see 2.26.2.8) shall be permanently located on the car top and readily accessible to a person, while standing at the hoistway entrance	
	3.26.4	normally used for access to the car top.  b) The transfer switch [see 2.26.1.4.1(b)] shall be located on the car top and shall be so designed as to prevent accidental transfer from the "INSPECTION" to "NORMAL" position.	
		c) A separate device of the continuous-pressure type labeled "ENABLE" shall be provided adjacent to the inspection operating devices.	
		d) The inspection operating devices shall become effective only when the "ENABLE" device is activated.	
		e) The inspection operating devices [see 2.26.1.4.1(c)], shall be permitted to be of the portable type, provided	
		thati) the "ENABLE" device [see 2.26.1.4.2(c)], and a stop switch, in addition to the stop switch required in 2.26.1.4.2(a) are included in the portable unit	
		ii) the flexible cord is permanently attached so that the portable unit cannot be detached from the car top	
		2) Separate additional devices of the continuous pressure type shall be permitted to be provided on the car top to make power door opening and closing and automatic car leveling operative from the top of the car for testing purposes.	
Car Top Work Light	2.14.7.1.4	Must be provided with a guard     Car tops w/pendant style work lights must also be	
Light readings are to be taken in the direction of the light source.		equipped with a stationary fixture (Ore. amend.) 3) Light switch must operate both lights. 4) Must provide a minimum of 50 lx (5 ftc) as evenly distributed as possible	

TOP OF CAR 8	& HOISTWAY	Req.	COMMENTS	Cars 1-3
Clearances		•		
Car Top Minimum	n Runby	3.4.2.2	1) Minimum runby: (Max. 600 mm (24"));	
	Minimum	2	Enter measurements on data sheet	
Speed	Runby		a) Rated speeds to 0.50 m/s (100 fpm); 75mm (3");	
0.50 m/s	75 mm		b) From 0.50 – 1 m/s (100-200 fpm); 75-150mm (3-6");	
(100 fpm)	(3 in.)		c) > 1 m/s (200 fpm); 150 mm (6")	
0.75 m/s	115 mm			
(150 fpm)	(4-½ in.)			
1.0 m/s	150 mm			
(200 fpm)	(6 in.)	2 4 7	1) Minimum Aroas	
Refuge Space		3.4.7 (3.4.3)	1) Minimum Area: a) 0.51 m <sup>2</sup> (5.49 ft. <sup>2</sup> ), 600 mm (24") (one side)	
		(3.4.3)	b) 1100 mm (43 in.) high	
			c) the horizontal area of the refuge space shall be	
			outlined in a contrasting color on the car top.	
			2) In any area outside the refuge space where the vertical	N/A 🗌
			clearance between the top of the car enclosure and the	
			overhead structure or other obstructions is less than	
			specified in 2.4.12.1, the top of the car enclosure shall be	
			clearly marked.	
			a) The marking shall consist of  i) alternating 100 mm (4 in.) diagonal red and white	
			stripes.	
			ii) In addition, a sign with the words "DANGER LOW CLEARANCE"	
			iii) shall be prominently posted on the crosshead and be visible from the entrance.	
			b) The sign shall conform to ANSI Z535.2 or CAN/CSA-	
			Z321, whichever is applicable (see Part 9). The sign	
			shall be of such material and construction that the	
			letters and figures stamped, etched, cast, or	
			otherwise applied to the face shall remain	
Top of Car Claars	200	2.4.4	permanently and readily legible.	Enter on data
Top of Car Cleara Equipment Cleara		3.4.4 3.4.5	1) Minimum; Runby + Refuge = mm ( in.) 1) Minimum 150 mm (6") from overhead	Enter on data sheet
Horizontal Cleara		3.5	Minimum clearances required for all cars.	SHECE
(Refer to Oregon St		(3.14)	(*No Seismic requirements apply in a) & b) below)	
Code for Seismic zo	ones in Oregon.	2.5.1.1	a) Between car & hoistway; 20 mm (¾") min. on sides	
Typically all countie		_	not used for loading & unloading	
Cascade range are		2.5.1.3	b) Between cars; 50 mm (2") minimum.	
Eastern Oregon is z	LOITE ZD)	2.5.1.5	2) Car sill to hoistway or fascia for full width of	
Refer to Page 58	of the A17.1		opening;	
handbook.			a) 125 mm (5") maximum with horizontal doors.	
		8.4.1.1	<ul><li>b) 190 mm (7½") maximum with vertical doors.</li><li>3) Cwt. Seismic Clearance Requirements (where provided)</li></ul>	N/A
		0.7.1.1	a) Car to Cwt. assembly; minimum. 50 mm (2")	
			b) Car to Cwt. assembly w/double "U" brackets;	
☐ Evicting Equip	mont		minimum 100 mm (4").	
☐ Existing Equip	inclit		c) H/W to Cwt. assembly; minimum 50 mm (2").	
			d) Nearest obstruction to Cwt. assembly; minimum 25	
			mm (1").	
Normal Terminal	Limits	3.25.1	Normal Terminal Stopping Device     Topping Device	
			2) Emergency speed limit > 50 m/s (> 100 fpm)	
Crossbood Data	Diata	2.16	3) Final limit (optional)	
Crosshead Data F	rial <del>C</del>	3.16 (3.27)	Items to be included on the data plate:  1) Weight of combined car frame & cab	
		(3.21)	2) Rated load and speed	
			3) Wire rope data (when applicable)	
☐ Existing Equip	ment		4) Manufacturer's name	
_ 5 1~F			5) Year manufactured	

Page 18 of 36

Hydraulic Elevator Checklist 2004 Multi-car Group.doc Last Updated: 8/22/05

TOP OF CAR & HOISTWAY	Req.	COMMENTS	Cars 1-3
Floor Numbering	2.29.2	1) Numbers shall be not less than 100 mm (4") high	
Emergency Identification (Multiple cars in bldg. only)	2.29.1	Car Top number shall be not less than 50 mm (2") high on crosshead or car top in visible location	
Top Emergency Exit	2.14.1.5 (2.14.1.5.2)	The exit shall comply with the following:     a) Be not less than 0.26 m² (400 in²) & 400 mm (16") on any side	N/A 🗆
		b) Have a clear space above the car top not less than 1100 mm (43"); or	
		<ul> <li>A clear space of not less than 600 mm (24") with a clear angle of 60° if exit is partially obstructed.</li> </ul>	
		<ul> <li>d) Movable portion of suspended ceiling panels below escape hatch shall be restrained from falling.</li> </ul>	
		e) Exits not allowed on elevators in unenclosed H/W.	
Hoistway Construction  Rated  Non-rated	3.1 (2.1.1)	If the hoistway is fire rated, ensure that there are no open penetrations through interior surface of walls.	
Hoistway Smoke Control	3.1	1) Must be in compliance with the OSSC.	
(Does not include venting)	(2.1.4)	Pressurization is allowed. Air flow cannot interfere with the operation of the elevator or H/W equipment.	
Windows	2.1.5	1) Windows & skylights are not allowed	
Car Frame & Car Platforms	3.15	Check for loose connections on frame and platform.     Hillside washers or bevel headed bolts shall be used where applicable.	
Guide Rails & Fastenings	3.23	Shall conform to 2.23 except as noted in Req. 3.23.1.1	
Governors & Safeties	2.17 – 2.18	When provided, refer to Requirements 2.17.1 & 2.18.1	N/A 🗌
Car Top Enclosures Guardrails Refer to <b>2.10</b> for configuration of standard handrails.	2.14.1.7	Car top Guardrails are required when:  1) >300 mm (>12") from H/W enclosure to car (measured on all sides)	N/A 🗆
		Must be non-combustible     Withstand a lateral impact of 135kg (300#) without appreciable deformation	
		4) Shall be to a maximum height of 1100 mm (43") allowing for overhead clearances in Req. 2.4.6 & 2.4.7.	
		<ol> <li>Must extend from edge-to-edge. (Note: this requirement is not specified in code, but is necessary in order to protect the fall-potential.</li> </ol>	
Pipes, wiring and ducts	2.8.2	No unrelated wiring, ducts or piping allowed, except as noted in 2.8.2.1 to 2.8.2.3.	
		Sprinkler branch lines and risers must be located outside hoistway.	
	2.8.1.4 (OR Amend)	Electrical conduit, fittings and covers must be as follows:     a) All wiring must be in approved raceway or conduit.	
	(Ort/uncha)	b) (348-12) Conduit Supports every 3.048 m (10') & within 914 mm (3') of boxes.	
		c) (362-8) Gutter Supports shall not exceed: i) Horizontal Runs; 1524 mm (5') to 3048 mm (10') ii) Vertical Runs; 4572 mm (15')	
		d) (370-18) Plug Open "knockouts" e) (370-25) Outlet box covers must be provided.	
		f) (370-28c) J-box covers required.	
Projections & Recesses	2.1.6	The following shall apply:     a) Only sills, headers, etc. may project into hoistway on entrance sides.	
		b) Recesses are prohibited except to install elevator equipment.	
		c) Ledges over 100 mm (4") must be beveled not less than 75°	
	Ore. Amend	<ul> <li>d) Top of setbacks shall be beveled at not less than 75°</li> <li>e) Glass enclosure framing may no more than 127 mm (5") without beveling if no hazard exists.</li> </ul>	

Hydraulic Elevator Checklist 2004 Multi-car Group.doc Last Updated: 8/22/05

TOP OF CAR & HOISTWAY	Req.	COMMENTS	Cars 1-3
Hoistway Door Locking Devices (Req. 2.12.2)	2.12.1	Passenger Elevators:         a) Must be equipped with interlocks         b) Listed to UL104 standard	N/A
Req. 2.11.11.7: Multi-panel Entrances. Panels shall be with hoistway door interlocks on each driven panel, and provided with door closer(s) installed to comply with Req.	2.12.1 2.12.3	2) Freight Elevators:  a) Must be equipped with interlocks  b) Under 4572 mm (15') rise may have combination contacts and locks  c) Locking elements must be engaged by 7.14 mm (9/32") before car can start.	N/A
2.11.11.7.1 or 2.11.11.7.2. All panels shall move simultaneously when the car is at the landing.	2.12.4.1 2.12.4.2	3) Door Locks must comply with the following:  a) Subjected to lab tests specified in Part 8.3.3 (listed to UL104).  4) Identification marking shall be as follows:  a) Manufacturer's name or logo  b) Lab name or logo  c) Model or style number or letter  d) Rated voltage (AC or DC)  e) Rated current  f) Rated test force & movement (for interlocks released by retiring cam)	
Traveling Cables	2.8.1	g) Month & year tested by lab  1) Traveling Cables must conform to the following: a) (620-11) Must comply with Table 400 b) (620-41) Properly supported at 30 m (100') or 61 m (200') lengths c) (620-43) Shall be protected from damage and snags d) (620-44) Run in lengths no greater than 1830 mm (72") outside gutter or conduit. e) (620-83) Be properly grounded to the car.	

Last Updated: 8/22/05

TOP OF CAR & HOISTWAY	Req.	COMMENTS	Car 1-3
Hoistway Doors	2.11	Check for proper type of door arrangement:	
Indicate Type	(3.17) 2.11.2.1	Passenger elevators:     A Horizontal slide (ADA requirement) Vertical allowed	N/A 🗆
S/Sp. Side Slide	2.11.2.1	<ul> <li>a) Horizontal slide (ADA requirement) Vertical allowed for non-ADA elevators</li> </ul>	
☐ ☐ ☐ 2/Sp. Side Slide	2.11.11.4	b) Upthrust device	
3/Sp. Side Slide	2.11.11.5.1	c) Overlap on multi-speed doors, min. 13 mm (1/2").	
│	2.11.11.5.2	<li>d) Maximum clearance between panels and frames, 10 mm (3/8").</li>	
□ □ □ 3/Sp. C/O	2.11.11.5.4	e) C/O doors must have astragal.	
Single Swing	2.11.11.5.5	f) Raised molding, etc., max. 3.0 mm (1/8")	
☐ ☐ ☐ Double Swing ☐ ☐ ☐ Swing/Horizontal	2.11.11.5.7	<li>g) Must withstand 2104 N (526 lbf) applied at right angles to center of panel</li>	
Comb.	2.11.11.6	h) Gibs must engage sill by min. 6.35 mm (¼".)	
☐ ☐ ☐ S/Sp. Vertical	2.11.11.8	i) Safety retainers (fire stops)	
☐ ☐ ☐ 2/Sp. Vertical ☐ ☐ ☐ 3/Sp. Vertical	2.11.11.10 2.11.12	j) Door/sight guard to sill edge 13 mm (½") 3) Freight Elevators:	│
Bi-parting	2.11.12	a) Horizontal slide (see Req. 2.14.6.2 for clearances)	
☐ ☐ MANUAL		b) Swing, single section	
□ □ □ POWER	2.11.13 2.11.13.5	c) Horizontal-swing combination	
<b>2.11.11.5</b> ; "They shall be	2.11.13.5	<ul><li>d) C/O two section horizontal swing</li><li>e) Bi-parting counterbalanced</li></ul>	
securely anchored to the sills,		f) Vertical slide counterweighted	
and to the building structure or	2.11.12.8	g) Pull straps for manual door types 'e' and 'f' above	
to the track supports such that they shall withstand the forces		h) Double swing (limitations apply see Req.2.11.2.3) 4) Other door requirements:	
shown in Regs. 2.11.11.3.1 and		a) Sill guards or fascia	
2.11.11.8 without detachment	2.11.14/15	b) Door panel listing & marking	
or permanent deformation.  Anchors and fastenings to suit	2.11.7.1 (4.3.3)	c) Vision Panels;	N/A
the wall construction are	(4.0.0)	ii) Wired or laminated glass (Z97.1 or 16 CFR 1201	
required. The head of the		iii) Maximum total area: 0.055 m² (85 in²)	
entrance frames shall not be		<ul><li>iv) Power Doors; must be substantially flush w/outside surface of door.</li></ul>	
used to support the weight of the wall over the frame."		v) Must be protected by grill work; see Rule	
		2.11.7.1.7 for details.	
2.11.7.1.7 Vision Panel		<ul> <li>vi) Required with manually operated or self closing hoistway doors at landings w/o position indicator</li> </ul>	
Grillwork: 1: Cover the entire panel.	2.11.7.2.2	d) Glass panels;	N/A
2: Openings no larger then		i) Min. 60% of visible door area from outside	
19mm x 19mm (¾"x ¾" or		hoistway; ii) Glass must be marked; and	
19mm (3/4") diameter. 3. Openings shall be spaced		ii) Glass must be marked; and iii) Limited to one glass panel.	
25 mm (1") on center.		5) Ensure smoke doors cannot prevent egress from the car	N/A
4: Installed on h/w side and		or access to the car.  6) Frames; overlap wall on hoistway side & provide a	
free from burrs and sharp		<ol><li>Frames; overlap wall on hoistway side &amp; provide a uniform surface with wall.</li></ol>	
edges.	2.11.11.3	7) Securely anchored to wall and sill.	
		8) Wall and doorframes must interface as per drawings to	
	2.11.15	maintain listed fire rating.  9) Marking & labeling of tested assembly; lab name, symbol	
	-	or file no., statement of compliance w/8.3.4.	
		2 11 11 5 7 "The entrance eccembly shall be constituted	
		2.11.11.5.7 "The entrance assembly shall be capable of withstanding a force of 2500 N (562 lbf) applied on the landing	
		side at right angles to and approximately at the center of a	
		panel. This force shall be distributed over an area of	
		approximately 100 mm (4 in.) by 100 mm (4 in.). There shall be no appreciable permanent displacement or deformation of	
		any parts of the entrance assembly resulting from this test."	


OUTSIDE HOISTWAY	Req.	COMMENTS	Cars 1-3
Hoistway Enclosure	2.1.1	1) Ensure there are no questionable openings in enclosure	
,	(4.8.3)	around entrance frames.	
		2) If glass is used ensure that laminated glass is provided and	
		properly marked.	
Emorgonov dooro	2.11.1.1-2	Other items may need to be deferred to the building official     Not normally required on hydraulic elevators. However if	
Emergency doors	(4.10.3)	situation warrants, see Req. 2.11.11.1 & 2.11.11.2	
Car Platform Guard	3.15	1) Min. height of the leveling zone plus 75 mm (3"), but not	
Sai i lationii Saara	(4.1.3)	less than 525 mm (21") high.	
	{refer to	2) Minimum 1.5 mm (0.059 in) thick steel or equivalent	
	2.15.9}	material.	
		3) Must be equal to or greater than width of door opening.	
		<ul> <li>4) Lower portion beveled between 60° &amp; 75°</li> <li>5) Must be adequately supported</li> </ul>	
Access to Hoistway	2.12.6.1	5) Must be adequately supported 1) Door Unlocking Devices	N/A
Access to Floistway	(4.5.3)	a) Hoistway door unlocking devices shall be provided	
	( 7	for use by authorized and emergency personnel for	
		each car at every landing where there is an entrance.	
		b) Door unlocking access cannot be more than 2100	N/A
	2.12.6.2.5	mm (83") from floor level.	
		c) Keys are Security Group 1 2) Hoistway Access Switches	N/A
	2.12.7.1.1	a) Hoistway access switches required for speeds > 0.75	
		m/s (150 fpm)	
	2.12.7.1.2	b) < 0.75 m/s (150 fpm) switches required if top of car is	
		more than 900 mm (36") from sill with car at next	
		lower landing.	
	2.12.7.3.2	c) Located at the lowest & top landings only. d) Maximum operating speed; 0.75 m/s (150 fpm.)	
	2.12.7.0.2	e) Access cannot be operative if TOC inspection station	
		is active.	
		f) Bottom landing: upward travel limited to point where	
		bottom of toe guard is even with header.	
		g) Other landings:	
		<ul> <li>i) downward travel is limited to a point where car top is even with landing sill.</li> </ul>	
		ii) Upward travel limited to length of toe guard	ппп
Hall Stations	A117.1	1) 1070 mm (42") to center line of fixture	
	4.10.3	2) 19 mm (3/4") min. button size	
Door Jamb Braille Markings	A117.1	1) 1525 mm (60") on center from floor.	
Fire Coming Circus Dhana I	4.10.5	ON I and a discount to the Dis	
Fire Service Signs, Phase I Fire Signs, Use Stairway	2.27.7 OSSC	2) Located adjacent to the Phase I keyed switch     Nequired by the building code. See A17.1 Appendix O for	
i ile Siglis, Ose Stallway	3002.3	1) Required by the building code. See A17.1 Appendix O for sample pictograph. May be only one per group-system.	
Standby Emergency Power	2.27.2.3	An illuminated signal marked "ELEVATOR EMERGENCY	N/A 🗌
	(4.12)	POWER" shall be provided in the elevator lobby at the	
The key shall be Group 3		designated level to indicate that the normal power supply	
Security (see 8.1); and		has failed and the emergency or standby power is in	
	2.27.2.4.1	effect. 2) A selector switch(es) marked "ELEVATOR EMERGENCY"	
	2.21.2.4.1	POWER" in red lettering a minimum of 5 mm (0.25 in.) in	
		height; and	
	2.27.2.4.2	3) The selector switch(es) positions shall be marked to	
		correspond with the elevator identification number (see	
		2.29) and a position marked "AUTO."	


Completed for: Car 1-0 2-0 3-0 Page 22 of 36 Hydraulic Elevator Checklist 2004 Multi-car Group.doc

OUTSIDE HOISTWAY	Req.	COMMENTS	Cars 1-3
Corridor Illumination	2.11.10.2	1) Minimum 100 lx (10 ftc) @ floor level w/doors closed.	Enter Values
☐ Existing Equipment		2) Take nominal readings in front of each group of cars. In	on Data
Davis Olasian af Haiaturu	0.40.0.4	larger lobbies, multiple readings may be necessary.	Sheet
Power Closing of Hoistway  Doors	2.13.3.1 (4.6.3)	1) Manual H/W Door w/Power Car Door	N/A 🗌
Doors	(4.0.3)	a) When the car door is closed under power by automatic means created by momentary push button	
		or timer control, the hoistway door must be closed	
		before the car door can close. This feature not	
		required if car door is controlled via constant	
		pressure push button.	
	2.13.3.2	2) Power Closing of Car & H/W doors via CPPB. (Horizontal	N/A 🗌
		or vertical)	
		<ul> <li>a) Gates and doors shall stop, or stop and reopen.</li> <li>Sequencing is not required.</li> </ul>	
	2.13.3.3	3) Power Closing of Car & H/W horizontal doors	N/A □
	2.10.0.0	a) Automatic or momentary means pressure control.	
	2.13.4.2.1	b) Kinetic energy must be observed and door open	
		button required.	
	2.13.3.4	4) Power Closing of Car & H/W doors by automatic means.	N/A 🗌
Sequence Operation Required		(Vertical doors)	
		<ul> <li>a) Requires an audible warning device to sound at least</li> <li>5 sec. prior to doors beginning to close. Delay may</li> </ul>	
		be omitted if close is started by push button.	
		Sequence closing is required; door open button is	
		required and a door-reopening device is required.	
Anti-creep	(3.26.3.1)	1) Maintain car within 25.40 mm (1") of floor level.	
		2) Operate at a maximum speed of 0.125 m/s (25 fpm.)	
		3) Sign on disconnect shall read:	
		a) "KEEP SWITCH CLOSED EXCEPT FOR MAINTENANCE, REPAIRS, AND INSPECTIONS"	
		4) Letters shall be a minimum 6.35 mm (½") high.	
		5) Sign shall be of durable material	
		6) Anti-creep shall not operate if the following are activated:	
		a) Recycling operation	
		b) TOC inspection	
		c) Hoistway access d) Low oil timer	
		e) Oil tank temperature shutdown	
Emergency Numbering	2.29.1	Elevator number is required at the designated level on	
(Multiple cars in bldg. only)		each entrance frame.	
		a) Minimum 75 mm (3-in.) high	
Auxiliary Power Lowering	3.26.10	1) Permitted, but not required.	N/A 🗆
Device (Battery Lowering Device)		2) Door open/close buttons shall be operable	
(Battery Lowering Device)		May bypass or render inoperative,     a) landing and car calls	
		b) designated operation (attendant or hospital service)	
		c) devices initiating emergency recall operation (refer to	
		3.27)	<u> </u>
		d) fire operation (refer to 3.27)	
		4) Intermediate stops are allowed for descending car	
		5) Power doors shall open and close after a predetermined time. (The predetermined time is not specified by code).	
Symbols	OSSC	"Star of Life" symbol [elevators with 4 or more stops]	N/A 🗆
27.18010	3002.4	placed on at least one elevator with an interior to	
		accommodate a 24" x 76" stretcher.	
		2) The symbol must be 75 mm (3-in.) in height and located	
		on both sides of the entrance frames. The height from the	
_		floor is not specified but should be placed above the jamb tag.	
		ı uy.	<u> </u>

Completed for: Car 1-0 2-0 3-0 Page 23 of 36 Hydraulic Elevator Checklist 2004 Multi-car Group.doc

OUTSIDE HOISTWAY	Req.	COMMENTS	Cars 1-3
Minimum Hall Call Door Time  T=D/1.5 ft/s; or  T=D/455 mm/s	A117.1 4.10.1.7	The minimum acceptable time from notification that a car is answering a call until the doors of that car start to close shall be calculated from one of the following equations (see left column) where T = total time in seconds and D = distance (ft. or mm) from the point in the lobby or corridor 60 in. (1525 mm) directly in front of the farthest call button controlling that car to the centerline of its hoistway door.	Enter Values on Data Sheet





PIT AREA	Req.		COMMENTS	Cars 1-3
Pit Access	2.2.4		ers shall be installed in all pits greater than 900	N/A 🗌
(Ladder design must comply with ANSI A14.3, Standard for Fixed Ladders.)	(5.1)	a) Min	") deep and shall conform to the following: imum 400 mm (16") wide unless reduced to allow elevator equipment (min. 225 mm (9") in any	
Walk-in Pit: Yes ☐ No ☐		cas b) Rur	e) ngs 300 mm (12") on center	
☐ Existing Condition		d) Be obs	end a minimum 1200 mm (48") above sill level not less than 180 mm (7-in.) from wall or nearest struction behind ladder. May be reduced to a	
		e) Be	imum of 115 mm (4½") when necessary.  not less than 1000 mm (39") measured izontally from means to unlock egress door from	
	2.2.2.4	2) Pit Acce	ess Doors:imm 1825 mm (72") high by 750 mm (29.5")	N/A 🗆
		wid	е	
		c) Key	f-closing & self locking /s to be kept on premises – Security Group 1	
		of	oor swings out and structural or mechanical part elevator projects into the door ening:	
		i)	Door contact required	
		ii)	Vision panel required: (1) wired or laminated glass	
			(2) minimum 6 mm (¼") thick (3) reject a 150 mm (6 in) diameter ball	
		o\ Par	(4) max. area of .03 m <sup>2</sup> (47 in <sup>2</sup> ) rier required if door sill is more than 300 mm (12	
		in.)	above pit floor.	
	2.2.8	a) Wh	to Underside of Car:ere the distance from the pit floor to the underside	N/A 🗌
			the plank channels or slings exceeds 2100 mm -in.), with the car at the lowest landing, a means	
		sha	Ill be permanently installed or permanently stored he pit to provide access to the equipment on the	
		und	lerside of the car.	
Stop Switch	2.2.6		by the access door; or when access is through anding door:	
		2) Approx.	457 mm (18") above sill level; er 1700 mm (67") deep require a second stop	
		switch lo	ocated about 1200 (47") from floor.	
Lighting & Light Switch	2.2.5 (5.1)		g shall apply: n 100 lx (10 ftc) illumination evenly distributed	
(Illumination shall be taken in direction of light source and	(/	<ol><li>Light sw</li></ol>	vitch located within easy reach of access door	
readings should be done at least in	2.2.5.4 (OA)	l) Fixtures	) shall be guarded are to be of the type that will not allow installation	
front and back of the pit channels with the hoistway door closed.		of lamps lx (10ftc	s of light output less than required to produce 100	
Depending on pit area, more than 1 reading may be necessary.)	620-24		on a dedicated branch circuit and not on load	
	2.2.5.5 (OA)	3) Illumina	tion measurements are to be taken in the	
		unection	n of the light source.	

PIT AREA	Req.	COMMENTS	Cars 1-3
Sump Pump or Drain (Sump Pumps and drains are to be installed according to the <b>Oregon Plumbing Specialty Code</b> .	2.2.2.3 710.15	May be provided with the following:     a) Sump pump with 24hr monitored alarm and power control switch located outside hoistway     Oregon Plumbing Specialty Code requires:	
Discharge line location:	(OPSC)	Permanent means of drainage shall be provided for elevator pits. Gravity drains, when installed, shall be provided with an approved type backwater valve to prevent drain line backup and the trap seal shall be protected with an automatic trap	
☐ Existing Equipment		seal primer. Sump and pump may be installed when provided with the following:	
		<ul> <li>a) A check valve to prevent water, gases, and odors from entering the pit.</li> </ul>	
		<ul><li>b) A secured and level cover over the sump.</li><li>c) An automatic activation switch</li></ul>	
		<ul><li>d) A minimum 1/3 hp rating.</li><li>e) A minimum 1¼ (32 mm) discharge pipe.</li></ul>	
		f) Sump size as recommended by the manufacturer.	
		g) The outlet pipe of the pump shall be directly or indirectly connected to the inlet of a primed "P" trap.	
		The "P" trap shall be connected to the sanitary	
		drainage system. h) Single pumps shall be permitted.	
	620-85	<ul><li>3) Connected to a dedicated non-GFCI single receptacle</li><li>4) Sump shall be readily accessible for maintenance</li></ul>	
Sump cover	2.2.2.6	1) Covers shall be:	
		<ul><li>a) Substantially level with pit floor.</li><li>b) Non-combustible</li></ul>	
		c) Prevented from shifting sufficiently to expose sump	
		opening. d) Fastenings should not be of the non-removable type.	
Access to Pit Equipment  Oregon Amendment	2.2.4.5	1) Where elevated pit equipment requires vertical access of more than 1220-mm (48-in.), a permanent non-	
Note: This requirement only		combustible working platform shall be provided.	
pertains to pits depths not covered under 2.2.8.		2) The platform's height and surface area shall be determined by the equipment requiring access.	
		<ul><li>3) Access to the platform shall be by fixed ladder or stair.</li><li>4) The platform shall be of sufficient strength to support</li></ul>	
		personnel and may be of open grillwork.	
		5) Platform railings, where required, shall comply with ANSI 1264.1.	
Plunger and Cylinder  D Direct Plunger	3.18.3.3	Ensure the following:     a) Plunger does not bottom out with car on buffers.	
Holeless	3.18.3.7	b) Oil collection not more than 19 L (5 gal.)	
	3.18.3.8	c) Below ground installations are provided with: i) Monitored cathodic protection	
		ii) Cylinder coating iii) Protective Casing	
	3.18.3.9	d) Cylinder air and gas relief	
Bottom Clearances	3.18.4 3.4.1	e) Stop ring 1) Bottom Clearances shall be as follows:	
		a) Minimum 600 mm (24") to any equipment installed under platform except within a 300 mm (12") wide	
		perimeter from the platform edge. This includes the	
	3.4.1.6	bolster channels. b) If vertical clearance outside refuge area <600 mm (24"), shall be clearly marked w/red & white striping &	
		<ul><li>"DANGER LOW CLEARANCE" sign.</li><li>c) The refuge space shall be not less than:</li></ul>	
		i) 600 mm (24")w x 1200 mm (48")l x 600 mm (24")h; or	
		ii) 450 mm (18")w x 900 mm (36")l x 1070 mm (42")h	

Hydraulic Elevator Checklist 2004 Multi-car Group.doc Last Updated: 8/22/05

PIT AREA	Req.	COMMENTS	Cars 1-3
Bottom Runby	3.4.2.1	1) Minimum runby: (max. 600 mm (24");	04.010
,,		Enter measurements on data sheet.	
		a) Not less than 0.50 m/s (100 fpm); 75 mm (3");	
		b) From 0.50 – 1 m/s (100-200 fpm); 75 mm-150 mm	
		(3"-6");	
		c) >1 m/s (200 fpm); 150 mm (6")	
Car Buffer	3.22.1	1) Solid bumpers may only be used on cars with rated	
	(2.22)	speed of 0.25 m/s (50 ft/min.) or less.	
		a) Spring buffers#	
No. and Confe	0.05.4	b) Oil buffers #	
Normal Limits	3.25.1	1) Normal limits shall:	
		<ul><li>a) Be operated by movement of the car</li><li>b) Slow and stop the car in down direction</li></ul>	
		c) Function independently of the normal stopping	
		circuits	
		d) Final limit is optional	
Car Frame & Platform	3.15.1.1.4	Ensure plunger connection on direct plunger systems will	
		not separate from car.	
		2) All bolster, side stile and platform fastenings are secure	
		3) Check for loose connections on frame and platform.	
		4) Hillside washers or bevel headed bolts shall be used	
		where applicable.	—
		5) Class B & C loading:	N/A 🗆
		a) Platform stringers shall be of steel or other metals	
		6) Class A loading:	N/A 🔲
		<ul> <li>a) Platform stringers may be of steel, wood or other metals.</li> </ul>	
		7) Wood Platforms:	N/A 🗆
		a) Must be covered with sheet metal or a fire retardant	
		material; or	
		b) Covered with a fire retardant coating.	
Guiding Members	3.23	Ensure guide rail brackets in pit area are securely fastened	
Traveling Cables & Electrical	2.8.2	Traveling Cables must conform to the following:	
G		a) (620-11) Must comply with Table 400	
		b) (620-43) Shall be protected from damage and snags	
		c) (620-44) Run in lengths not greater than 6' outside	
		gutter or conduit from point of suspension on car.	
		d) (620-83) Be properly grounded to the car.	
		e) Must not contact pit floor with car resting on buffers	
		2) When the pit is sprinklered, electrical equipment located less than 1220 mm (48") above pit floor must be (when	
		not monitored by shunt trip):	
	2.8.2.3.5	a) NEMA-4 enclosed (weatherproof); and	
		b) Wiring identified for use in wet locations.	
Supply Piping	3.19	Ensure piping is of appropriate size. (If piping is not appropriate size.)	
		distinguishable as to its rating; require documentation as	
		to its characteristics.)	
		2) Ensure joints are properly fastened and there are no	
		leaks	
		3) Connections shall only be one or more of the following	
		types: (mark the appropriate type)	
		a) Welded	ᅵ႘님님ㅣ
		b) Threaded	
		c) Grooved	
	3.19.4.2	d) Bolted flange 4) An additional shut-off valve is required in the pit (Ore.	
	3.18.4.2	4) An additional shut-off valve is required in the pit (Ore. Amend).	
	L	j Amonu).	

Completed for: Car 1-0 2-0 3-0 Page 27 of 36 Hydraulic Elevator Checklist 2004 Multi-car Group.doc

PIT AREA	Req.	COMMENTS	Cars 1-3
Seismic Pipe Supports (restraints)	8.4.11.3	Pipe Support Spacing:  1) Locate supports near changes in direction, near valves and joints.	
		Pipe Size Maximum Spacing	
		1" 1525 mm (60")	
		1½" 2300 mm (90")	HHH
		2" 2600 mm (102")	HHH
		2½" 2750 mm (108")	HHH
		3" 3000 mm (120")	
		4" 3500 mm (138")	
GFI 15 & 20 Amp Receptacles	NEC	1) Must be of the GFI type.	
Hydraulic Pipeline	620-85 3.19.2.5	<ul><li>2) Shall not extinguish pit lighting if tripped.</li><li>1) A marking shall be applied, to accessible piping that is</li></ul>	N/A □
Identification.	3.19.2.3	located outside the elevator machine room or hoistway, stating "Elevator Hydraulic Line" in letters that are at least	
		19 mm (0.75 in.) high in a contrasting color.	
		<ol> <li>The marking shall be visible after installation and applied at intervals not greater than 3 000 mm (120 in.).</li> </ol>	
Comments:			_

Page 28 of 36 Completed for: Car 1-0 2-0 3-0 Hydraulic Elevator Checklist 2004 Multi-car Group.doc

Locks & Gate Switches Bypassed. 2	<b>Req.</b> 2.26.1.5	1) The following shall be provided and located in the machine	
Bypassed. 2		,	N/A 🗌
	.26.1.5.2	room: a) Car door bypass switch	ппп
2	.26.1.5.1	b) Hoistway door bypass switch	
		c) Clearly labeled with "bypass" and "open" positions	
	26.1.5.3	d) Contacts opened mechanically & not dependent solely	$\sqcup \sqcup \sqcup$
Individual switches may be used to bypass groups of door 2	.26.1.5.4	on springs e) Use of relays shall not render door locks inoperative if	
locks.	20.1.0.4	relay fails	
2	.26.1.5.8	f) Shall only allow operation of car in inspection mode	
<b>2.26.1.4</b> Machine room		g) When both switches are in bypass mode car can be	
inspection operation is not	.26.1.5.8	operated by only car-top or in-car inspection control.  h) Warning sign required adjacent to bypass switches:	
allowed when door lock bypass 2 switches are engaged.	20.1.3.0	i) "Jumpers shall not be used to bypass	ппп
dimense are origagea.		hoistway-door or car-door electric contacts"	
Faulty Door Lock Monitoring	2.26.5	1) A means is required to monitor positions of power-	
System		operated car doors mechanically coupled to hoistway	
		doors when at landing zone.  2) Operation must be prevented if car door is open even if	
		gate switch is electrically closed.	
		3) Doors must be prevented from closing if fully open when:	
		(except in Req. 2.26.1.5).	
		a) Car door contact is made or bypassed	
		<li>b) The hoistway door at the landing is closed or bypassed.</li>	шшш
Seismic/Overspeed Valve	8.4.11.2	Test with full load in car. Visually witness test to ensure	
·		valve arrests downward movement of the car with rated	
Seismic Req. 8.4.11.2		load.	
Overspeed Valve Req. 3.19.4.7	.19.4.7.2	Provide dated tag and seal valve.     Marking:	шшш
Tested, tagged & sealed:	. 10.4.7.2	a) Manufacturer's name or trademark	
1□ 2□ 3□		b) Type designation	
		c) Component-rated pressure	
3	.19.4.7.3	d) Maximum & minimum rated flow. 4) Location:	шшш
	. 10.4.7.0	a) Single jack arrangements:	
		i) Within 300 mm (12") of hydraulic cylinder	
		b) Multiple jack arrangements:	
		i) May have one valve located within 300 mm (12") of each jack; or	
		ii) May be positioned immediately before the tee.	
		5) Tripping speed:	
		a) Minimum 110% of operating speed	
Pressure Relief	3.19.3.2	<ul><li>b) Maximum 140% of operating speed</li><li>Witness setting of hydraulic valve and record pressure</li></ul>	
ll l	(2.14.3)	settings.	Enter
	•	2) Test to be performed with rated load in car. Relief to be	readings on
		set with car against stop ring.	data sheet
Low Oil Protection	3.26.9	<ul><li>3) Relief setting shall not exceed 150% of working pressure.</li><li>1) Suitable methods include:</li></ul>	
25.7 5.1 15.6561011	5.25.5	a) Direct sensing of liquid level; or	
		b) Pump run-timer; or	
		c) Other means;	
		Upon activation the car shall:         a) Return to the lowest level & after door time, doors	
		shall close & require manual reset.	
Test Log	8.11.1.7	1) Ensure log is marked with test date and placed in visual	
	(Ore.	location within machine room	
	Amend)	1) Dequired when top of cylinder is above took Witness	N/A 🗌
Pressure Switch	3.26.8	<ol> <li>Required when top of cylinder is above tank. Witness actuation of this device.</li> </ol>	

Completed for: Car 1-0 2-0 3-0 Page 29 of 36 Hydraulic Elevator Checklist 2004 Multi-car Group.doc

TESTING	Req.	COMMENTS	Cars 1-3
Low Oil Protection	3.26.9	1) Suitable methods include:	
		a) Direct sensing of liquid level; or	
		b) Pump run-timer; or	ᅟ님님님ㅣ
		c) Other means; 2) Upon activation the car shall:	
		a) Return to the lowest level &	
		b) after door time, doors shall close &	
		c) requires a manual reset of system.	
Shunt Trip Device	2.8.2.3.2	Activation device may be either:	N/A 🗌
Heat Detectors Located:		a) Heat detector located within 610 mm (24") of	
Hoistway 🔲 🔲 🗎		sprinkler head; or	
Machine Rm. □□□		b) Flow sensor without time delay device.     c) Device must be supervised through the fire alarm	.
Machine Riff.		c) Device must be supervised through the fire alarm panel.	
Pit 🔲 🗎 🗎		Shunt-trip must be located in elevator machine room.	. nnn l
		3) Ensure that opening the disconnect will not trigger an	
		alarm or trouble signal.	
Speed Test	8.11.3.2.3(cc)	Tachometer speed test; verify car speed in both directions:	
	(3.30.3)	Up: ☐ m/s ☐ fpm	
		Dn: ☐ m/s ☐ fpm	
	NFPA	72 (2002) National Fire Alarm Code	
6.15.4 Elevator Shutdown			
		own elevator power prior to sprinkler operation, the detector shall I	nave both a
lower temperature rating and a h			
		elevator power prior to sprinkler operation, they shall be placed with	
		rdance with the requirements of Chapter 5. Alternatively, engineer	
		o be used to select and place heat detectors to ensure response p	rior to any
sprinkler head operation under a		bwin rate scenarios. Ed to shut down elevator power immediately upon or prior to the dis	scharge of
		e delay switches or time delay capability shall not be permitted.	scriarge or
		wer shall be monitored for presence of operating voltage. Loss of v	oltage to the
		ause a supervisory signal to be indicated at the control unit and re	
annunciators.	ng meane enan e	adoo a supervisory digital to be indicated at the control and the	quired remote
II	escribed in 6.15.4	1.2 and 6.15.4.3 shall be monitored for integrity by the control unit	required in
6.15.3.1 and 6.15.3.2.		<b>3</b> , ,	•
ROPED HYDRAULIC			N/A 🗌
Car Safeties	3.17.1	Required on Roped Hydraulic Elevators:	
☐ Existing Equipment	{2.18.4.1}	a) SOS switch	
<b>Note:</b> The safety switches		b) Governor switch	
required must cause main drive		c) Overspeed switch for speeds > 0.75 m/s (150 fpm)	
power to be removed from the		d) Type A safeties for cars of 0.75 m/s (150 fpm) or less	
pump motor and control valve		e) Governor maximum tripping speed	
when safeties are activated.		i) 0-0.63 m/s (0-125 fpm) 0.75 m/s (175 fpm) trip	.
Enter tripping appeds at as		ii) 0.75 m/s (150 fpm) 1.10 m/s (210 fpm) trip	
Enter tripping speeds, etc. on data sheets.			,
Slack Rope Device	3.18.1.2.7	Slack rope switch must be of the enclosed manually reset	
Glack Nope Device	(3.31)	type.	
	(0.01)	2) May be used as an additional means to initiate safety	
		device	
Roping Ratio	3.18.1.2	1) Shall not exceed 1:2	
Governor Access	3.1	1) Access to governors shall be from outside the hoistway	
	Oregon	unless governor can be tested and reset from outside	
	Amendment	hoistway.	
Traveling Sheaves	3.23.2.2		N/A
	(3.32.3.2)	1) Minimum 40 times diameter of rope	
		2) Minimum permissible groove bottom diameter	
		3) Finished grooves or lining	

Completed for: Car 1-0 2-0 3-0 Page 30 of 36 Hydraulic Elevator Checklist 2004 Multi-car Group.doc

TESTING	Req.	COMMENTS	Cars 1-3
FIRE SERVICE			
Fire Service Phase I Recall Initiating Devices (Smoke detectors) (front/rear):  Phase I sign shall read:	2.27.3.1	Req. 2.27.3 does not apply if:  1) Hoistway is not required to be fire rated: and 2) Travel does not exceed 2000 mm (80"); and 3) Does not penetrate a floor Keys are designated Security Group 3	N/A
Fire Operation To recall elevators insert fire key and turn to "ON"  Detectors Tested	2.27.3.1.1>	<ol> <li>Phase-I 3-position keyed switch in lobby (RESET-OFF-ON). Key removable in OFF-ON position only.</li> <li>"FIRE RECALL" letters to be 5 mm (½") high in RED or</li> </ol>	
Cars Landing Alt. 1 2 3 (Front) Landing	2.27.3.1.2>	color contrasting with a red background.  3) Optional secondary 2-position keyed switch (if any) (OFF-ON) {FIRE RECALL shall not restore elevator	
1 <sup>st</sup>	2.27.3.1.3>	<ul><li>operation if this switch is ON}</li><li>4) Keys rotate clockwise from Reset-Off-On; keys removable in ON &amp; OFF positions only.</li></ul>	
□□□ 2 <sup>nd</sup> □□□ 3 <sup>rd</sup>	2.27.3.1.4>	<ul><li>5) Only fire recall switches and lobby, M/R or H/W detectors allowed to put elevator(s) on recall.</li></ul>	
□□□ 4 <sup>th</sup>	2.27.3.1.5>	6) Illuminated signal required with Phase I switches to indicate Phase I activation.	
5 <sup>th</sup> 6 <sup>th</sup> 7 <sup>th</sup>	2.27.3.1.6>	7) Phase I operation:  a) Car(s) traveling toward recall level;  b) Car(s) traveling away from recall level;  c) Car(s) stopped at landings.	
□□□ Machine room □□□ Hoistway • N/A	2.27.3.1.6(i)	<ul> <li>d) Ensure RUN-STOP-OVERRIDE is functional upon car leaving the landing.</li> </ul>	
Cars Landin	2.27.3.1.6(c)	<ul> <li>e) Door reopening devices susceptible to smoke or flame shall be disabled.</li> </ul>	
1 2 3 (Rear)	2.27.3.1.6(e) ref. 2.13.5.1	<li>f) Must close under reduced speed: max. 3.5J (2.5 ft- lbf kinetic energy)</li>	
	2.27.3.1.6(f)	g) Ensure all hall and car calls are canceled; hall/car lanterns are disabled.	
4 <sup>th</sup>	2.27.3.1.6(h)	Visual and Audible signals     a) An illuminated visual and audible signal system shall be activated.	
2.27.3.2.1		<ul> <li>b) The visual signal shall be one of the symbols shown in Fig. 2.27.3.1.6(h) and located on the car operating panel.</li> </ul>	
Detectors are to be located at each elevator lobby (optional at unenclosed landings) machine		<ul> <li>c) The entire circular or square area of the outline of the hat, or the outline of the area shown on fig. 2.27.3.1.6(h) shall be illuminated.</li> </ul>	
room and at the top of the hoistway if the top of the		<ul> <li>d) The visual signal shall remain activated until the car is restored to automatic operation.</li> </ul>	
hoistway is sprinklered or the detector is used to activate a		e) When the door is open, the audible signal shall remain active for a minimum of 5 s.	
smoke control system. Refer to NFPA 72 (2002) for		f) The audible signal shall not be active when the car is at the recall level.	
additional details.	2.27.3.1.6(j)	Additional Fire Recall switch:     a) Both Fire recall switches must be in the on position to recall elevator to main egress level if called to alternate landing first.	
	2.27.3.1.6(k)	b) Removing elevator from Phase I Recall: i) Primary switch turned to Reset, then Off; ii) Second switch is in the Off position; and iii) Fire alarm devices are reset.	
	2.27.3.1.6(I)	10) Means to remove elevators from service cannot interfere with Phase I recall unless specified in code.	N/A
	2.27.3.1.6(m)	11) Load weighing cannot override Fire Recall.	


TESTING	Req.	COMMENTS	Cars 1-3
FIRE SERVICE (Phase I cont.)	2 27 2 2 2	1) Fire Alema Initiating Device Astivistics	
Fire Alarm Initiating Devices (Smoke Detectors)	2.27.3.2.3	Fire Alarm Initiating Device Activation:         a) Lobby Detectors (other than main landing)	
		i) All cars serving that landing and any group cars shall return to the main egress level	
		Machine Room Detectors     a) All cars with equipment in the M/R and any group	
		cars return to the main egress level unless M/R is on the main level.	
		b) Cause the fire hat to illuminate intermittently.	
		All cars in the hoistway and any group cars shall	
		return to designated level.	
		<ul> <li>b) Detectors activated below the lowest landing will cause cars to return to the highest recall level.</li> </ul>	
		c) Cause the fire hat to illuminate intermittently.	
		Main Lobby Detectors	
		b) If Fire Recall switch is already in the ON position,	
		cars shall return to the main egress level.	
		5) The recall level shall be determined by the first activated fire alarm initiating device for the group.	
	2.27.3.2.5	6) When designated-attendant operation is not in effect,	
	0.07.5.1	elevators shall conform to 2.27.3.	
	2.27.5.1	When operated by a designated attendant in the car, except hospital service:	
	2.27.5.2	a) Elevators parked at a floor shall conform to	
		2.27.3.1.6(h). At the completion of a time delay of not less than 10 s and not more than 30 s, elevators	
		shall conform to 2.27.3.	
	2.27.5.3	b) A moving car shall conform to 2.27.3.  8) When on hospital service, the elevator shall conform to	
	2.27.3.3	2.27.3.1.6(h) while Phase I Emergency Recall Operation	
		is in effect.	
		<ol> <li>An elevator on firefighter emergency operation shall not be placed on hospital service.</li> </ol>	
	2.27.6	10) Firefighters' Emergency Operation — Inspection	
		Operationa) When an elevator that is provided with firefighters'	
		service is on inspection operation (see 2.26.1.4 and	
		2.26.1.5) or when the hoistway access switch(es)	
		have been enabled [see 2.12.7.3.3(a)], a continuous audible signal, audible at the location where the	
		operation is activated shall sound when the "FIRE	
		<b>RECALL</b> " switch(es) (see 2.27.3.1) is in the " <b>ON</b> " position or when the fire alarm initiating device (see	
		2.27.3.2) is activated to alert the operator of an	
		emergency.	
		b) The car shall remain under the control of the operator until removed from inspection operation or	
		hoistway access operation.	
		c) Inspection operation or hoistway access operation shall take precedence over Phase I Emergency	
		Recall Operation and Phase II Emergency In-Car	
		Operation.	


TESTING FIRE SERVICE (CONT)	Req.	COMMENTS	Cars 1-3
FIRE SERVICE (CONT) Fire Service Phase II	2.27.3.3	1) 3-position keyed switch:	
2.27.7.2	2.27.3.3	a) Provided with "OFF-HOLD-ON" positions, in that order. b) labeled "FIRE OPERATION"	
Phase II Sign Shall read:  "FIRE OPERATION"		i) labeling is to be a min. of 5 mm (¼") high in <b>RED</b> letters or colors contrasting with a red background.	
"When [fire helmet] flashes, exit elevator"		c) key is only removable in "OFF" and "HOLD" positions. 2) Made active only at the designated level after Phase-I is activated.	
To Operate Car: Insert fire key and turn to "ON";	2.27.3.3.1	a) Power operated doors opened by constant pressure of DO button	
Press desired floor button		b) Doors must reach full open in order to remain open otherwise they are to close immediately	
To cancel floor selection: Press "CALL CANCEL" button		<ul> <li>c) Doors shall close via constant pressure on DC button.</li> <li>If released doors are to reopen if not fully closed.</li> </ul>	
To close power operated		<ul> <li>d) Door open and close buttons are to be provided for each entrance to the car.</li> </ul>	
door: Press and hold "DOOR CLOSE"		Door reopening devices are to be disabled; full speed closing is permitted.	
button		f) CALL CANCEL button shall extinguish all registered car calls.	
To open power operated door:		g) All floor buttons are to be operative. h) Car must stop at first registered call and extinguish all	
Press and hold "DOOR OPEN" button		calls i) Hall buttons to remain inoperative j) Directional lanterns to remain inoperative	
To hold car at floor: With doors open, turn key to "HOLD"		k) Hall Pl's except at designated level and central control center shall remain inoperative.  l) Car Pl to remain operative m) Every car shall be provided with a switch, conforming	
To automatically send car to		to the requirements of 2.26.2.33 and located as required by 2.27.3.37.	
recall floor: With doors open, turn key to "OFF"		i) When the switch is in the "STOP" position, all registered calls shall be canceled and power shall be removed from the elevator driving	
Lettering must be a minimum of 3.0 mm (1/8") high, permanent and protected against removal or		machine motor and brake.  ii) When the switch is moved to the "RUN" position from the "STOP" position, the car shall not move, except for leveling, until a call is entered.	
defacement.	2.27.3.3.2	HOLD position activated with doors open; no car operation possible.	
	2.27.3.3.3	4) Car at landing with the doors open and Phase II switch OFF:	
		<ul><li>a) Car is not at designated level;</li><li>b) Horizontal &amp; vertical doors shall close automatically if</li></ul>	
		powered; c) Door open buttons shall remain operative; d) Full speed closing is permitted;	
		e) Doors to reopen if switch is turned to HOLD before doors get closed.	
	2.27.3.3.4	Car is stopped with doors closed <u>and</u> Phase II switch is turned OFF:	
	2.27.3.3.5	<ul> <li>a) Car shall remain on Phase II operation; and</li> <li>b) Return to the designated level.</li> <li>3) Car can only be taken off Phase II when at the</li> </ul>	
	2.27.3.4	designated level. 4) Loss of power test: Ensure that when power is restored	
	2.27.8	elevator reverts to Phase-I or Phase-II.  5) Keys shall be Group 3 Security	

Page 33 of 36

Hydraulic Elevator Checklist 2004 Multi-car Group.doc Last Updated: 8/22/05

TESTING FIRE SERVICE (CONT)	A17.1 (A17.2)	COMMENTS	CARS 1-3
Fire Service Operation Panel	2.27.3.3.7	1) The following switches and buttons shall be located in a panel with a locked cover located above the main COP:  a) "FIRE OPERATION" switch (2.27.3.3), b) "CALL CANCEL" button [2.27.3.3.1(h)], c) "STOP" switch [2.27.3.3.1(m)], d) door open button(s), e) door close button(s), f) additional visual signal (2.27.3.3.8), and g) operating instructions shown in Fig. 2.27.7.2  2) The panel cover:  a) shall be openable by the same key that operates the "FIRE OPERATION" switch. b) shall be permitted to open automatically when the car is on Phase I Emergency Recall Operation and at the recall level. c) When the key is in the "FIRE OPERATION" switch, the cover shall not be capable of being closed. d) When closed, the cover shall be self-locking. 3) Where rear doors are provided: a) buttons for both the front and rear doors shall be provided in the firefighters' operation panel. b) the door open and close buttons for the rear entrance shall be labeled "OPEN REAR" and "CLOSE REAR".  4) All buttons and switches	
Additional Visual Signal	2.27.3.3.8	<ol> <li>An additional visual signal shall be provided and located as required by 2.27.3.3.7.</li> <li>The additional visual signal shall be one of the symbols shown in Fig. 2.27.3.1.6(h).</li> </ol>	
		3) The entire circular or square area shown in Fig. 2.27.3.1.6(h) shall be illuminated.	
See Fig. 2.27.3.1.6(h) below.		<ol> <li>This additional visual signal shall be activated whenever the visual signal in 2.27.3.1.6(h) is activated.</li> </ol>	





GENERAL NOTE: Grid is for scaling purposes only.




Fig. 2.27.3.3.7 Panel Layout

	Indicate Recall Landing		
Detector Location	Car #1	Car #2	Car #3
1 <sup>st</sup> Landing			
2 <sup>nd</sup> Landing			
3 <sup>rd</sup> Landing			
4 <sup>th</sup> Landing			
5 <sup>th</sup> Landing			
6 <sup>th</sup> Landing			
7 <sup>th</sup> Landing			
Hoistway			
Machine Room			

#### NFPA 72 (2002) National Fire Alarm Code (cont.)

6.15.3.9 Actuation from elevator hoistway and elevator machine room smoke detectors or other automatic fire detection as permitted by 6.15.3.7 shall send an alarm condition on the building fire alarm. system and shall visibly indicate, at the control unit and required annunciators, the alarm initiation circuit or zone from which the alarm originated.

Exception: If approved by the authority having jurisdiction, the elevator hoistway and machine room smoke detectors shall be permitted to initiate a supervisory signal.

- 6.15.3.10 For each group of elevators with a building, a minimum of three separate elevator control circuits shall be terminated at the designated elevator controller within the group's elevator machine room(s). The operation of the elevators shall be in accordance with Section 2.27 of ANSI/ASME A17.1 Safety Code for Elevators and Escalators. The smoke detectors or other automatic fire detection as permitted by 6.15.3.7 shall actuate the three elevator control circuits as follows:
- (1) The smoke detector or other automatic fire detection as permitted by 6.15.3.7 located in the designated elevator recall lobby shall actuate the first elevator control circuit. In addition, if the elevator is equipped with front and rear doors, or the elevator machine room is located at the designated level, the smoke detectors shall actuate the first elevator control circuit. The smoke detectors or other automatic fire detection as permitted by 6.15.3.7 in both lobbies at the designated level shall actuate the first elevator control circuit.
- (2) The smoke detectors or other automatic fire detection as permitted by 6.15.3.7 in the remaining elevator lobbies shall actuate the second elevator control circuit.
- (3) The smoke detectors or other automatic fire detection as permitted by 6.15.3.7 in the elevator hoistways and the elevator machine room(s) shall actuate the third elevator control circuit.

#### 6.15.4 Elevator Shutdown

- 6.15.4.1 Where heat detectors are used to shut down elevator power prior to sprinkler operation, the detector shall have both a lower temperature rating and a higher sensitivity as compared to the sprinkler.
- 6.15.4.2 If heat detectors are used to shut down elevator power prior to sprinkler operation, they shall be placed within 610 mm (2 ft) of each sprinkler head and be installed in accordance with the requirements of Chapter 5. Alternatively, engineering methods, such as specified in Annex B, shall be permitted to be used to select and place heat detectors to ensure response prior to any sprinkler head operation under a variety of fire growth rate scenarios.
- 6.15.4.3 If pressure or waterflow switches are used to shut down elevator power immediately upon or prior to the discharge of water from sprinklers, the use of devices with time delay switches or time delay capability shall not be permitted.
- 6.15.4.4 Control circuits to shut down elevator power shall be monitored for presence of operating voltage. Loss of voltage to the control circuit for the disconnecting means shall cause a supervisory signal to be indicated at the control unit and required remote annunciators.
- 6.15.4.5 The initiating devices described in 6.15.4.2 and 6.15.4.3 shall be monitored for integrity by the control unit required in 6.15.3.1 and 6.15.3.2.

Completed for: Car 1-0 2-0 Page 35 of 36 3-0 Hydraulic Elevator Checklist 2004 Multi-car Group.doc

#### **Addition Comments**