

듣 Eckert & Ziegler

RETURN KIT INSTRUCTIONS

Isotope Products

Please read these instructions thoroughly to ensure proper packaging of your return source(s).

Dear Valued Customer,

In an effort to assist you in returning your sources to Eckert & Ziegler Isotope Products (EZIP), we are providing you with two options within this return kit:

OPTION A: DOT Excepted Package (Limited Quantities) Source Return:

If you are returning a source and the dose rate readings on the surface of the packaged source are below 0.5 mRem/hour, please go to www.ezag.com/home/business-segments/isotope-products/ customer-support.html and download the forms under the section titled "Instructions for Packaging Sources for Recycling". These forms include (items in red are required as part of the shipment):

- Instructions for Packaging of Sources for Recycling
- Emergency Response Information (UN2910)
- Excepted Package Certificate
- EZIP Return Label

In addition to the forms found online, in this envelope you will also find the following:

- Excepted Package (UN2910) Label (x2)
- FedEx Airbill and pouch
- Packing List Envelope
- Packing List Form (Form "B" on the reverse of this sheet)



OPTION B: DOT Category II-Yellow Source Return:

If you are returning a source and the dose rate readings on the surface of the packaged source are 0.5 mRem/hour or above, please go to www.ezag.com/home/business-segments/isotope-products/ customer-support.html and download the forms under the section titled "Instructions for Packaging of Radioactive Sources". These forms include (items in red are required as part of the shipment):

- Shipper's Declaration for Dangerous Goods •
- Instructions for Packaging of Radioactive Sources
- Emergency Response Information (UN2915)
- DOT Type A Box Marking Label this label reads "RADIOACTIVE MATERIAL, TYPE A PACK-AGE UN2915, NON SPECIAL FORM, NON FISSILE OR FISSILE EXCEPTED, USA-D.O.T-7A-TYPE A". NOTE: UN2915 shipments require a Type A certified box. This wording is already included on Type A boxes, however, this label can be used in the event that the wording has been defaced or has become illegible. If you require a Type A box, please contact EZIP Sales.
- **EZIP** Return Label

In addition to the forms found online, in this envelope you will also find the following:

- Radioactive II Label (x2)
- FedEx pouch for Shipper's Declaration For Dangerous Goods
- FedEx Airbill and pouch
- Packing List Envelope
- Packing List Form (Form "B" on the reverse of this sheet)



Should you have any guestions with regards to your return, please contact EZIP Sales at (661) 309-1010.

RETURN PACKING LIST

All information must be provided to ensure proper handling of your return

FROM:						SEND TO:		
Company Name								
Address Eckert & Ziegl								
City	1		State)	Isotope Products		
Contact Name						1800 North Keystone Street		
Telephone	Fax				Burbank, CA 91504 Telephone: (661) 309-1010			
Email						Fax: (661) 257-8303 Email: nucmedsales@ezag.com		
RETURN # RA- a copy placed to EZIP must For additional					a copy placed in to EZIP must be For additional re	cking list must be affixed to the <u>OUTSIDE</u> and inside of the package. Each returned source e on a <u>one-to-one</u> exchange basis only. returns, please contact EZIP customer service cost considerations.		
Nuclide Activity	Refere Activity Dat				Capsule Description		Source Wipe Test ≤ 5nCi	
1)							_ 🗆 Yes 🗆 No	
2)							_ 🗆 Yes 🗆 No	
3)							_ 🗆 Yes 🗆 No	
4)							_ 🗆 Yes 🗆 No	
If source is damaged, broken, or leaking, describe under "Capsule Description" section and submit a copy of the last leak test. Keep a copy of this form for your records. It may be requested by your regulatory agency. I acknowledge that the above information is true to the best of my knowledge. Contact's Signature: Shipper's 24 Hour Emergency Response Number (Required):								
FOR EZIP USE ONLY								
EZIP has received the radioactive sources listed above, except as noted below Receiver's Name:								
Receiver's Name:								

Receipt Date:

Sources not received: