


DN744000TX

Driness Drop Leaf Table

ASSEMBLY INSTRUCTIONS



Holly & Martin® a valued brand of SEI
Customer Service [1-800-633-5096](tel:1-800-633-5096)
service@hollyandmartin.com
www.hollyandmartin.com















DN74400TX Driness Drop Leaf Table

Parts List

Please review all parts and hardware before disposing of any packaging.
Call Customer Service if missing hardware.

Using a screw that is too long will cause damage.

Before beginning assembly, separate each type of screw. Carefully study the Screw diagrams below. You may receive extra hardware with your unit.

A  Quantity Of 5 Long bolt (M6*50mm)	B  Quantity Of 1 Allen wrench	C  Quantity of 4 glass holder(φ 10*18*M6)
D  Quantity Of 11 screw (φ 3.5*15mm)	E  Quantity Of 8 Adjustable leveler (φ 33*M8)	F  Quantity Of 16 short bolt (M6*45mm)
1  Quantity Of 1 Middle Top panel	2  Quantity Of 1 Side Top panel	3  Quantity Of 1 Top metal frame
4  Quantity of 1 BOTTOM METAL FRAME	5  Quantity of 2 leg frame 1	6  Quantity of 2 leg frame 2

Care and Cleaning Instructions:

Before using, wipe with a clean, dry cloth.
Periodically apply furniture wax to renew the finish. Avoid rubbing or scratching the surface with rough or abrasive objects.

For replacement parts or questions, please

Call Customer Service at 1-800-633-5096

Please call manufacturer for assistance, questions or Parts.

Assembly Tool Required

No.2 Phillips Screwdriver (Not Included)



DN744000TX Driness Drop Leaf Table

Assembly Instructions




Figure 1

Unpack and lay parts on clean, padded surface like carpet or blanket. Check that you have all parts indicated on the front page.

Attach top metal frame (3) to leg frame 1 (5) & leg frame 2 (6) using short bolt (F) as shown.

Tighten short bolt (F) with Allen wrench (B).





Figure 2

Turn over unit in figure 1


Attach bottom metal frame (4) to leg frame 1(5) & leg frame 2 (6) using short bolt (F) as shown.

Tighten short bolt (F) with Allen wrench (B).



Attached side top panel (2) to middle top panel (1) using screw (D), Tighten screw (D) using Phillips screwdriver (not included).


Figure 3



Connect pre-assembled unit in Figure 2 and pre-assembled unit Figure 3 by inserting long bolt (A) into the five holes of top metal frame(3) as shown.


Tighten long bolt (A) with Allen wrench (B).

Figure 4



Insert pin stopper (C) into holes on back of top panel (1). (These pins function as a stopper when top panel is in folded position.)


Figure5



Screw adjustable leveler (E) into the bottom of the table leg.

(Please adjust each stopper so that the table is stable)


Figure 6




With an assistant, turn the table upright.

Now you can enjoy your new dining table.

Figure 7



Close leg frame
by hand



Converting to a console

Please carefully fold both sides of leg frames first before folding down the two (top) side panels.

Top panel support up to 50 lbs

drop leaf support up to 15 lbs

Figure 8

Parts Replacement Form

Customer Information

Name _____

Address _____

City/State/Zip Code _____

Phone Number _____

Please indicate where you purchased this item: Store/Website/Catalog

Please indicate color/size/style number:

Style No	Parts Letter	Parts Description	Quantity Needed
----------	--------------	-------------------	-----------------

-------	--	--	--

-------	--	--	--

-------	--	--	--

Please immediately examine this product carefully. Any request for missing parts or damage replacement must be received within 90 days of your receipt of the product. Replacement, if available, will be honored within this time frame. Parts will not be available for items arriving fully assembled. We do not recommend modifying product(s) and we are not responsible for any damages due to product modification(s). If damages or missing parts are not reported within 90 days of your receipt, we are under no obligation to provide parts or replacement merchandise.

Please contact Southern Enterprises at 800-633-5096 or in Dallas 972-869-0111/ 9am – 4pm Mon-Fri Central time if you have product issues or email us at service@hollyandmartin.com. Please ask for customer service representative for issues involving damages or replacement parts. Please ask for technical assistance representative for any issues with product and assembly/construction.

Please contact the retailer that you purchased from for returns.



Customer Service [1-800-633-5096](tel:1-800-633-5096)

service@hollyandmartin.com

www.hollyandmartin.com

600 Freeport Parkway, Suite 200
Coppell, Texas 75019