



- NOTES:
- 1) Builder to verify all dimensions and truss spans.
 - 2) All dimensions are from face of studs.
 - 3) Dimensions are in ft.-in.-16th.
 - 4) Do not erect truss backwards.
 - 5) Cutting or drilling of chords is NOT allowed.
 - 6) All walls shown on layout assumed to be load bearing.
 - 7) All jack truss are connected per Toe-Nail detail.
- Roof Area : = 1437.84

HANGERS		
SYMBOL	TYPE	QTY
A	HUS26	6
B	N/A	N/A
C	N/A	N/A
D	N/A	N/A
E	N/A	N/A

PROBUILD

Norcross Truss Facility
 4094 Blueridge Ind Pky
 Norcross, GA 30071

PHONE: 770-813-2200 FAX: 770-813-2209

CUSTOMER: **SDC**

Model: **Manchester F**

Layout Type: **Roof Truss Layout**

Loading: **20-10-10**

Job Number: **MnchstrF**

Spacing: **24" O.C.**

Date: **5/30/2013**

Drawn By: **G.Hill**

Code: **IRC 2006**

Scale: **NTS**

THIS LAYOUT IS THE SOLE SOURCE FOR FABRICATION OF TRUSSES AND VOIDS ALL PREVIOUS ARCHITECTURAL OR OTHER TRUSS LAYOUTS, REVIEW AND APPROVAL OF THIS LAYOUT MUST BE RECEIVED BEFORE ANY TRUSSES WILL BE BUILT. BY SIGNING I AM VERIFYING ALL CONDITIONS TO INSURE AGAINST CHANGES THAT WILL RESULT IN EXTRA CHARGES. BACKCHARGES WILL NOT BE ACCEPTED WITHOUT PRIOR APPROVAL BY PROBUID WITHIN 48 HOURS OF DELIVERY.

THIS IS A TRUSS PLACEMENT DIAGRAM ONLY. These trusses are designed as individual building components to be incorporated into the building design at the specification of the building designer. See individual design sheets for each truss design identified on the placement drawing. The building designer is responsible for temporary and permanent bracing of the roof and floor system and for the overall structure. The design of the truss support structure including headers, beams, walls, and columns is the responsibility of the building designer. For general guidance regarding bracing, consult "Bracing of Wood Trusses" available from the Truss Plate Institute, 583 D'Onofrio Drive, Madison, WI 53179.

Shop Drawing Approval

Approved By: _____ Date: _____